

**700/800-Series  
MVME162LX  
Embedded Controller  
Installation and Use**

V162-7A/IH1

## **Notice**

While reasonable efforts have been made to assure the accuracy of this document, Motorola, Inc. assumes no liability resulting from any omissions in this document, or from the use of the information obtained therein. Motorola reserves the right to revise this document and to make changes from time to time in the content hereof without obligation of Motorola to notify any person of such revision or changes.

No part of this material may be reproduced or copied in any tangible medium, or stored in a retrieval system, or transmitted in any form, or by any means, radio, electronic, mechanical, photocopying, recording or facsimile, or otherwise, without the prior written permission of Motorola, Inc.

It is possible that this publication may contain reference to, or information about Motorola products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Motorola intends to announce such Motorola products, programming, or services in your country.

## **Restricted Rights Legend**

If the documentation contained herein is supplied, directly or indirectly, to the U.S. Government, the following notice shall apply unless otherwise agreed to in writing by Motorola, Inc.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Motorola, Inc.  
Computer Group  
2900 South Diablo Way  
Tempe, Arizona 85282-9602

## Preface

This document provides general information and basic installation instructions for the 700/800-series MVME162LX VME Embedded Controller, which is available in the versions listed below.

<b>Assembly Item</b>	<b>Board Description</b>	<b>Assembly Item</b>	<b>Board Description</b>
MVME162-723	32MHz, 4MB DRAM	MVME162-813	32MHz, 8MB DRAM
MVME162-743	32MHz, 4MB ECC DRAM	MVME162-833	32MHz, 8MB ECC DRAM
MVME162-763	32MHz, 16MB ECC DRAM	MVME162-853	32MHz, 32MB ECC DRAM
		MVME162-863	32MHz, 16MB ECC DRAM

In *700/800-Series MVME162LX Embedded Controller Installation and Use* you will find a general board-level hardware description, hardware preparation and installation instructions, a description of the debugger firmware, and information on using the firmware on the MVME162LX VME Embedded Controller.

This manual is intended for anyone who wants to design OEM systems, supply additional capability to an existing compatible system, or work in a lab environment for experimental purposes. A basic knowledge of computers and digital logic is assumed.

Companion publications are listed beginning on page 1-3.

## **Safety Summary**

### **Safety Depends On You**

The following general safety precautions must be observed during all phases of operation, service, and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment. Motorola, Inc. assumes no liability for the customer's failure to comply with these requirements.

The safety precautions listed below represent warnings of certain dangers of which Motorola is aware. You, as the user of the product, should follow these warnings and all other safety precautions necessary for the safe operation of the equipment in your operating environment.

#### **Ground the Instrument.**

To minimize shock hazard, the equipment chassis and enclosure must be connected to an electrical ground. The equipment is supplied with a three-conductor AC power cable. The power cable must be plugged into an approved three-contact electrical outlet. The power jack and mating plug of the power cable must meet International Electrotechnical Commission (IEC) safety standards.

#### **Do Not Operate in an Explosive Atmosphere.**

Do not operate the equipment in the presence of flammable gases or fumes. Operation of any electrical equipment in such an environment constitutes a definite safety hazard.

#### **Keep Away From Live Circuits.**

Operating personnel must not remove equipment covers. Only Factory Authorized Service Personnel or other qualified maintenance personnel may remove equipment covers for internal subassembly or component replacement or any internal adjustment. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

#### **Do Not Service or Adjust Alone.**

Do not attempt internal service or adjustment unless another person capable of rendering first aid and resuscitation is present.

#### **Use Caution When Exposing or Handling the CRT.**

Breakage of the Cathode-Ray Tube (CRT) causes a high-velocity scattering of glass fragments (implosion). To prevent CRT implosion, avoid rough handling or jarring of the equipment. Handling of the CRT should be done only by qualified maintenance personnel using approved safety mask and gloves.

#### **Do Not Substitute Parts or Modify Equipment.**

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification of the equipment. Contact your local Motorola representative for service and repair to ensure that safety features are maintained.

#### **Dangerous Procedure Warnings.**

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed. You should also employ all other safety precautions which you deem necessary for the operation of the equipment in your operating environment.



Dangerous voltages, capable of causing death, are present in this equipment. Use extreme caution when handling, testing, and adjusting.

## Lithium Battery Caution

The board contains a lithium battery to power the clock and calendar circuitry.



Danger of explosion if battery is replaced incorrectly. Replace only with the same or equivalent type recommended by the equipment manufacturer. Dispose of used batteries according to the manufacturer's instructions.



Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.



Explosionsgefahr bei unsachgemäßem Austausch der Batterie. Ersatz nur durch denselben oder einen vom Hersteller empfohlenen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

All Motorola PWBs (printed wiring boards) are manufactured by UL-recognized manufacturers, with a flammability rating of 94V-0.



This equipment generates, uses, and can radiate electro-magnetic energy. It may cause or be susceptible to electro-magnetic interference (EMI) if not installed and used in a cabinet with adequate EMI protection.



European Notice: Board products with the CE marking comply with the EMC Directive (89/336/EEC). Compliance with this directive implies conformity to the following European Norms:

EN55022 (CISPR 22) Radio Frequency Interference

EN50082-1 (IEC801-2, IEC801-3, IEC801-4) Electromagnetic Immunity

The product also fulfills EN60950 (product safety), which is essentially the requirement for the Low Voltage Directive (73/23/EEC).

This board product was tested in a representative system to show compliance with the above mentioned requirements. A proper installation in a CE-marked system will maintain the required EMC/safety performance.

The computer programs stored in the Read Only Memory of this device contain material copyrighted by Motorola Inc., 1995, and may be used only under a license such as those contained in Motorola's software licenses.

Motorola<sup>®</sup> and the Motorola symbol are registered trademarks of Motorola, Inc.

All other products mentioned in this document are trademarks or registered trademarks of their respective holders.

©Copyright Motorola 1997  
All Rights Reserved

Printed in the United States of America  
October 1997

# Contents

---

Lithium Battery Caution	5
Introduction	1-1
Overview	1-1
Related Documentation	1-3
Documents for the MVME162LX	1-4
Other Applicable Motorola Publications	1-4
Applicable Non-Motorola Publications	1-5
Requirements	1-6
Features	1-6
Specifications	1-9
Cooling Requirements	1-10
Special Considerations for Elevated-Temperature Operation	1-10
FCC Compliance	1-12
Manual Terminology	1-12
Block Diagram	1-14
Functional Description	1-14
Front Panel Switches and Indicators	1-14
Data Bus Structure	1-16
Microprocessor	1-16
MC68040 Cache	1-16
No-VMEbus-Interface Option	1-17
Memory Options	1-17
DRAM Options	1-17
SRAM Options	1-18
About the Battery	1-19
EPROM and Flash Memory	1-21
Battery Backed Up RAM and Clock	1-21
VMEbus Interface and VMEchip2	1-21
I/O Interfaces	1-22
Serial Communications Interface	1-22
IndustryPack (IP) Interfaces	1-23
Optional Ethernet Interface	1-23
Optional SCSI Interface	1-24
SCSI Termination	1-24
Local Resources	1-25
Programmable Tick Timers	1-25
Watchdog Timer	1-25

---

---

Software-Programmable Hardware Interrupts	1-26
Local Bus Timeout	1-26
Local Bus Arbiter	1-27
Connectors	1-27
Memory Maps	1-28
Local Bus Memory Map	1-28
Normal Address Range	1-28
VMEbus Memory Map	1-34
VMEbus Accesses to the Local Bus	1-34
VMEbus Short I/O Memory Map	1-34
Introduction	2-1
Unpacking Instructions	2-1
Hardware Preparation	2-1
System Controller Select Header (J1)	2-3
IP Bus Clock Header (J11)	2-5
SCSI Terminator Enable Header (J12)	2-6
SRAM Backup Power Source Select Header (J14)	2-6
Flash Write Protect Header (J16)	2-7
IP Bus Strobe Select Header (J18)	2-8
IP DMA Snoop Control Header (J19)	2-8
EPROM/Flash Configuration Header (J20)	2-9
General-Purpose Readable Jumpers Header (J21)	2-12
Memory Mezzanine Options	2-13
Installation Instructions	2-14
IP Installation on the MVME162LX	2-15
MVME162LX Installation	2-16
System Considerations	2-18
Overview of M68000 Firmware	3-1
Description of 162Bug	3-1
162Bug Implementation	3-3
Installation and Startup	3-3
Prom Versions	3-7
Autoboot	3-7
ROMboot	3-9
Network Boot	3-10
Restarting the System	3-10
Reset	3-11
Abort	3-11
Break	3-12
SYSFAIL* Assertion/Negation	3-12
MPU Clock Speed Calculation	3-13

---



---

- Memory Requirements 3-13
- Disk I/O Support 3-15
  - Blocks Versus Sectors 3-15
  - Device Probe Function 3-16
  - Disk I/O via 162Bug Commands 3-16
    - IOI (Input/Output Inquiry) 3-16
    - IOP (Physical I/O to Disk) 3-16
    - IOT (I/O Teach) 3-17
    - IOC (I/O Control) 3-17
    - BO (Bootstrap Operating System) 3-17
    - BH (Bootstrap and Halt) 3-17
  - Disk I/O via 162Bug System Calls 3-17
  - Default 162Bug Controller and Device Parameters 3-19
  - Disk I/O Error Codes 3-19
- Network I/O Support 3-19
  - Intel 82596 LAN Coprocessor Ethernet Driver 3-20
  - UDP/IP Protocol Modules 3-20
  - RARP/ARP Protocol Modules 3-21
  - BOOTP Protocol Module 3-21
  - TFTP Protocol Module 3-21
  - Network Boot Control Module 3-21
  - Network I/O Error Codes 3-22
- Multiprocessor Support 3-22
  - Multiprocessor Control Register (MPCR) Method 3-22
  - GCSR Method 3-24
- Diagnostic Facilities 3-25
- Manufacturing Test Process 3-25
- In This Chapter 4-1
- Entering Debugger Command Lines 4-1
  - Terminal Input/Output Control 4-1
  - Debugger Command Syntax 4-3
  - Syntactic Variables 4-3
    - Expression as a Parameter 4-3
    - Address as a Parameter 4-5
    - Address Formats 4-6
    - Offset Registers 4-7
  - Port Numbers 4-9
- Entering and Debugging Programs 4-9
  - Creating a Program with the Assembler/Disassembler 4-10
  - Downloading an S-Record Object File 4-10
  - Read the Program from Disk 4-10

---

---

Calling System Utilities from User Programs 4-11  
Preserving the Debugger Operating Environment 4-11  
    162Bug Vector Table and Workspace 4-12  
        Examples 4-12  
    Hardware Functions 4-13  
    Exception Vectors Used by 162Bug 4-13  
        Exception Vector Tables 4-15  
        Using 162Bug Target Vector Table 4-15  
        Creating a New Vector Table 4-16  
Floating Point Support 4-18  
    Single Precision Real 4-19  
    Double Precision Real 4-19  
    Scientific Notation 4-20  
The 162Bug Debugger Command Set 4-20  
Configure Board Information Block A-1  
Set Environment to Bug/Operating System A-3  
    Configuring the IndustryPacks A-14  
Disk/Tape Controller Modules Supported B-1  
Disk/Tape Controller Default Configurations B-2  
IOT Command Parameters for Supported Floppy Types B-4  
Network Controller Modules Supported C-1  
Solving Startup Problems D-1

---

# Board Level Hardware Description

# 1

## Introduction

This chapter describes the board level hardware features of the 700/800-series MVME162LX VME Embedded Controller. The chapter is organized with a board level overview and features list in this introduction, followed by a more detailed hardware functional description. Front panel switches and indicators are included in the detailed hardware functional description. The chapter closes with some general memory maps.

All MVME162LX programmable registers that reside in ASICs are covered in the *MVME162LX Embedded Controller Programmer's Reference Guide*.

## Overview

The MVME162LX is based on the MC68040 microprocessor. Various versions of the MVME162LX have parity-protected DRAM (4MB, 8M, or 16MB); or ECC-protected DRAM (4MB, 8MB, 16MB, or 32MB); 128KB of SRAM (with battery backup); a time-of-day clock (with battery backup); an optional LAN Ethernet transceiver interface; four serial ports with EIA-232-D interface; six tick timers with watchdog timer(s); two EPROM sockets; 2MB Flash memory (one Flash device); two IndustryPack (IP) interfaces with DMA; optional SCSI bus interface with DMA; and an optional VMEbus interface (local bus to VMEbus/VMEbus to local bus, with A16/A24/A32, D8/D16/D32 bus widths and a VMEbus system controller).

Input/Output (I/O) signals are routed through industry-standard connectors on the MVME162LX front panel; no adapter boards or transition modules are required. I/O connections include an optional 68-pin SCSI connector, an optional DB-15 Ethernet

connector, and four 8-pin RJ-45 serial connectors on the front panel. In addition, the panel has cutouts for routing of flat cables to the optional IndustryPack modules.

The following ASICs are used on the MVME162LX:

- ❑ **VMEchip2.** (VMEbus interface). Provides two tick timers, a watchdog timer, programmable map decoders for the master and slave interfaces, and a VMEbus to/from local bus DMA controller, a VMEbus to/from local bus non-DMA programmed access interface, a VMEbus interrupter, a VMEbus system controller, a VMEbus interrupt handler, and a VMEbus requester.

Processor-to-VMEbus transfers are D8, D16, or D32.

VMEchip2 DMA transfers to the VMEbus, however, are D16, D32, D16/BLT, D32/BLT, or D64/MBLT.

- ❑ **MC2chip.** Provides four tick timers, the interface to the LAN chip, SCSI chip, serial port chip, BBRAM, EPROM/Flash, parity DRAM and SRAM.
- ❑ **MCECC memory controller.** Provides the programmable interface for the ECC-protected DRAM mezzanine board.
- ❑ **IndustryPack Interface Controller (IP2).** The IP2 provides control and status information for up to two single-wide IndustryPacks (IPs) or one double-wide IP that can be plugged into the MVME162LX main board.

## Related Documentation

The MVME162LX ships with an installation and use manual (the document you are presently reading, Motorola publications number VME162-7A/IH) which includes installation instructions, jumper configuration information, memory maps, debugger/monitor commands, and any other information needed to start up the board.

If you plan to develop your own applications or need more detailed information about your MVME162LX VME Embedded Controller, you may wish to order the additional documentation listed on the following pages. You can contact Motorola for this purpose in several ways:

- ❑ Through your local Motorola sales office
- ❑ Through the World Wide Web site listed on the back cover of this and other MCG manuals
- ❑ (USA and Canada only) — By contacting the Literature Center via phone or fax at the numbers listed under *Product Literature* at MCG's World Wide Web site

If any supplements have been issued for a manual or guide, they will be furnished along with that document. Each Motorola Computer Group manual publication number is suffixed with characters which represent the revision level of the document, such as “/IH2” (the second revision of a manual); a supplement bears the same number as a manual but has a suffix such as “/IH2A1” (the first supplement to the second edition of the manual).

## Documents for the MVME162LX

The following MCG publications are applicable to the 700/800-series MVME162LX and may provide additional helpful information. If they are not shipped with this product, you can obtain them by contacting your local Motorola sales office.

<b>Motorola Publication Number</b>	<b>Description</b>
MVME162LXPG/D	MVME162LX Embedded Controller Programmer's Reference Guide
MVME162BUG/D	MVME162Bug Debugging Package User's Manual
68KBUG1/D 68KBUG2/D	Debugging Package for Motorola 68K CISC CPUs User's Manual (Parts 1 and 2)
SBCSCSI/D	Single Board Computers SCSI Software User's Manual

## Other Applicable Motorola Publications

The following publications are also applicable to the 700/800-series MVME162LX and may provide additional helpful information. They may be purchased through your local Motorola sales office.

<b>Motorola Publication Number</b>	<b>Description</b>
M68000FR	M68000 Family Reference Manual
M68040UM	MC68040 Microprocessors User's Manual

## Applicable Non-Motorola Publications

The following non-Motorola publications are also available from the sources indicated.

Document Title	Source
<p><i>VME64 Specification</i>, order number ANSI/VITA 1-1994</p> <p><b>Note:</b> An earlier version of the VME specification is available as <i>Versatile Backplane Bus: VMEbus, ANSI/IEEE Std 1014-1987</i> (VMEbus Specification). This is also available as <i>Microprocessor System Bus for 1 to 4 Byte Data</i> (IEC 821 BUS).</p>	<p>VITA (VMEbus International Trade Association) 7825 E. Gelding Dr., Ste. 104 Scottsdale, AZ 85260-3415</p>
<p><i>ANSI Small Computer System Interface-2 (SCSI-2), Draft Document X3.131-198X, Revision 10c</i></p>	<p>Global Engineering Documents 15 Inverness Way East Englewood, CO 80112-5704</p>
<p><i>82596CA Local Area Network Coprocessor Data Sheet</i>, order number 290218; and <i>82596 User's Manual</i>, order number 296853</p>	<p>Intel Corporation Literature Sales P.O. Box 58130 Santa Clara, CA 95052-8130</p>
<p><i>28F016SA Flash Memory Data Sheet</i>, order number 290435</p>	<p>Intel Corporation Literature Sales P.O. Box 7641, Mt. Prospect, IL 60056-7641</p>

Document Title	Source
<i>NCR 53C710 SCSI I/O Processor Data Manual</i> , order number NCR53C710DM	NCR Corporation Microelectronics Products Division 1635 Aeroplaza Dr. Colorado Springs, CO 80916
<i>NCR 53C710 SCSI I/O Processor Programmer's Guide</i> , order number NCR53C710PG	
<i>SGS-THOMSON 64K (8K x 8) Timekeeper® SRAM Data Sheet</i> , order number M48T08/18	SGS-THOMSON Microelectronics Group Marketing Headquarters 1000 East Bell Rd. Phoenix, AZ 85022-2699
<i>IndustryPack Logic Interface Specification</i> , Revision 1.0, order number ANSI/VITA 4-1995	VITA (VMEbus International Trade Association) 7825 E. Gelding Dr., Ste. 104 Scottsdale, AZ 85260-3415
Z85230 Serial Communications Controller Data Sheet	Zilog Inc. 210 Hacienda Ave. Campbell, CA 95008-6609

## Requirements

These boards are designed to conform to the requirements of the following documents:

- VME64 Specification, VITA
- EIA-232-D Serial Interface Specification, EIA
- SCSI Specification, ANSI
- IndustryPack Specification, VITA

## Features

The following table summarizes the features of the 700/800-series MVME162LX VME module.



**Table 1-1. 700/800-Series MVME162LX: Features**

Feature	Description
Microprocessor	32MHz MC68040
DRAM mezzanine	4/8/16MB with parity protection, or 4/8/16/32MB with ECC protection
SRAM	128KB static RAM (SRAM) with battery backup
EPROM	Two JEDEC standard 32-pin DIP PROM sockets
Flash memory	One Intel 28F016SA 2M x 8 Flash memory device with write protection (optional)
NVRAM	8K by 8 Non-Volatile RAM (NVRAM) and time-of-day (TOD) clock with battery backup
Switches	RESET and ABORT switches
Status LEDs	Status LEDs for FAIL, RUN, SCON, and FUSES
Tick Timers	Four 32-bit tick timers (in the MC2chip ASIC); two 32-bit tick timers (in the VMEchip2 ASIC) for periodic interrupts
Watchdog timers	Two 32-bit watchdog timers (one each in the MC2chip and VMEchip2 ASICs)
Interrupts	Eight software interrupts (for MVME162LX versions that have the VMEchip2)
Serial I/O	Four serial ports with EIA-232-D interface (serial port controllers are the Z85230 chips)
SCSI I/O	Optional SCSI Bus interface with DMA
Ethernet I/O	Optional Ethernet transceiver interface with DMA
IndustryPack I/O	Two IP interfaces with two-channel DMA

**Table 1-1. 700/800-Series MVME162LX: Features (Continued)**

Feature	Description
VMEbus interface	VMEbus system controller functions
	VMEbus interface to local bus (A24/ A32, D8/D16/D32/block transfer [D8/D16/D32/D64])
	Local-bus-to-VMEbus interface (A16/ A24/ A32, D8/D16/D32)
	VMEbus interrupter
	VMEbus interrupt handler
	Global control/ status register for interprocessor communications
	DMA for fast local memory - VMEbus transfers (A16/ A24/ A32, D16/D32/block transfer)

## Specifications

Table 1-2 lists the specifications for a 700/800-series MVME162LX without IPs.

**Table 1-2. 700/800-Series MVME162LX: Specifications**

Characteristics	Specifications
Power requirements (with EPROMs; without IPs)	+5Vdc ( $\pm 5\%$ ), 3.5 A typical, 4.5 A maximum +12 Vdc ( $\pm 5\%$ ), 100 mA maximum -12 Vdc ( $\pm 5\%$ ), 100 mA maximum
Operating temperature	0° to 70° C exit air with forced air cooling* (see Note)
Storage temperature	-40° to +85° C
Relative humidity	5% to 90% (noncondensing)
Physical dimensions	Double-high VMEboard
PC board with mezzanine module only	
Height	9.2 inches (233 mm)
Depth	6.3 inches (160 mm)
Thickness	0.66 inch (17 mm)
PC board with connectors and front panel	
Height	10.3 inches (262 mm)
Depth	7.4 inches (188 mm)
Thickness	0.80 inch (20 mm)
*Refer to <i>Cooling Requirements</i> on page 1-10 and <i>Special Considerations for Elevated-Temperature Operation</i> on page 1-10.	

## Cooling Requirements

The Motorola MVME162LX VME Embedded Controller is specified, designed, and tested to operate reliably with an incoming air temperature range from 0° to 55° C (32° to 131° F) with forced air cooling at a velocity typically achievable by using a 100 CFM axial fan. Temperature qualification is performed in a standard Motorola VME system chassis. Load boards are inserted adjacent to the board under test, to simulate a high power density system configuration. An assembly of three axial fans, rated at 100 CFM per fan, is placed directly under the VME card cage. The incoming air temperature is measured between the fan assembly and the card cage, where the incoming airstream first encounters the controller under test. Test software is executed as the controller is subjected to ambient temperature variations. Case temperatures of critical, high power density integrated circuits are monitored to ensure that component vendors' specifications are not exceeded.

While the exact amount of airflow required for cooling depends on the ambient air temperature and the type, number, and location of boards and other heat sources, adequate cooling can usually be achieved with 10 CFM and 490 LFM flowing over the controller. Less airflow is required to cool the controller in environments having lower maximum ambients. Under more favorable thermal conditions (refer to *Elevated-Temperature Operation* below), it may be possible to operate the controller reliably at higher than 55° C with increased airflow. It is important to note that there are several factors, in addition to the rated CFM of the air mover, which determine the actual volume and speed of air flowing over the controller.

## Special Considerations for Elevated-Temperature Operation

The following information is for users whose applications for the MVME162LX may subject it to high temperatures.

The MVME162LX uses commercial-grade devices. Therefore, it can operate in an environment with ambient air temperatures from 0° C to 70° C. Several factors influence the ambient temperature seen by components on the MVME162LX. Among them are inlet air temperature; airflow characteristics; number, types, and locations of IP modules; power dissipation of adjacent boards in the system, etc.

A temperature profile of a comparable board (the MVME172 embedded controller) was developed in an MVME954A six-slot VME chassis. Two such boards, each loaded with one 4MB memory mezzanine and two GreenSpring IndustryPack modules, were placed in the chassis with one 36W load board installed between them. The chassis was placed in a thermal chamber that maintained an ambient temperature of 55° C. Measurements showed that the fans in the chassis supplied an airflow of approximately 65 LFM over the MVME172 boards. Under these conditions, a rise in temperature of approximately 10° C between the inlet and exit air was observed. The junction temperatures of selected high-power devices on the MVME172 were calculated (from case temperature measurements) and were found to be within manufacturers' specified tolerances.

**Caution**

For elevated-temperature operation, perform similar measurements and calculations to determine the actual operating margin for your specific environment.

To facilitate elevated-temperature operation:

1. Position the MVME162LX in the chassis to permit maximum airflow over the component side of the board.
2. Do not place boards with high power dissipation next to the MVME162LX.
3. Use low-power IP modules only.

## FCC Compliance

The MVME162LX is a board-level product and is meant to be used in standard VME applications. As such, it is the responsibility of system integrators to meet the regulatory guidelines pertaining to a given application. The MVME162LX has been tested in a representative chassis for CE class B EMC certification. Compliance was achieved under the following conditions:

1. Shielded cables on all external I/O ports.
2. Cable shields connected to earth ground via metal shell connectors bonded to a conductive module front panel.
3. Conductive chassis rails connected to earth ground. This provides the path for connecting shields to earth ground.
4. Front panel screws properly tightened.

For minimum RF emissions, it is essential that the conditions above be implemented. Failure to do so could compromise the FCC compliance of the equipment containing the module.

## Manual Terminology

Throughout this manual, a convention is used which precedes data and address parameters by a character identifying the numeric format as follows:

\$	dollar	specifies a hexadecimal character
%	percent	specifies a binary number
&	ampersand	specifies a decimal number

For example, “12” is the decimal number twelve, and “\$12” is the decimal number eighteen.

Unless otherwise specified, all address references are in hexadecimal.

An asterisk (\*) following the signal name for signals which are *level significant* denotes that the signal is true or valid when the signal is low.

An asterisk (\*) following the signal name for signals which are *edge significant* denotes that the actions initiated by that signal occur on high-to-low transition.

In this manual, *assertion* and *negation* are used to specify forcing a signal to a particular state. In particular, *assertion* and *assert* refer to a signal that is active or *true*; *negation* and *negate* indicate a signal that is inactive or *false*. These terms are used independently of the voltage level (high or low) that they represent.

Data and address sizes are defined as follows:

- ❑ A *byte* is eight bits, numbered 0 through 7, with bit 0 being the least significant.
- ❑ A *two-byte* is 16 bits, numbered 0 through 15, with bit 0 being the least significant. For the MVME162LX and other CISC modules, this is called a *word*.
- ❑ A *four-byte* is 32 bits, numbered 0 through 31, with bit 0 being the least significant. For the MVME162LX and other CISC modules, this is called a *longword*.

The terms *control bit*, *status bit*, *true* and *false* are used extensively in this document.

The term *control bit* describes a bit in a register that can be set and cleared under software control. The term *true* indicates that a bit is in the state that enables the function it controls. The term *false* indicates that the bit is in the state which disables the function it controls. In all tables, the terms 0 and 1 describe the actual value that should be written to the bit, or the value that it yields when read.

The term *status bit* describes a bit in a register that reflects a specific condition. The status bit is read by software to determine operational or exception conditions.

## Block Diagram

Refer to [Figure 1-1 on page 1-15](#) for a block diagram of the 700/800-series MVME162LX.

## Functional Description


This section contains a functional description of the major blocks on the MVME162LX.

### Front Panel Switches and Indicators

There are two switches and four LEDs on the front panel of the MVME162LX.

- ❑ RESET switch. Resets all onboard devices (including IP modules, if installed) and drives SYSRESET\* if the board is system controller. The RESET switch may be disabled by software.
- ❑ ABORT switch. When enabled by software, the ABORT switch generates an interrupt at a user-programmable level. It is normally used to abort program execution and return to the 162Bug debugger.
- ❑ FAIL LED (red). Lights when the BRDFAIL\* signal line is active or when the processor is halted. Part of DS1.
- ❑ RUN LED (green or amber). Lights when the local bus TIP\* signal line is low. This indicates one of the local bus masters is executing a local bus cycle. Part of DS1.
- ❑ SCON LED (green). Lights when the VMEchip2 in the MVME162LX is the VMEbus system controller. Part of DS2.
- ❑ FUSES LED (green). Lights when +5Vdc, +12Vdc, and -12Vdc power is available to the LAN and SCSI interfaces and IP connectors. Part of DS2.





21009702

Figure 1-1. MVME162LX Block Diagram

## Data Bus Structure

The local bus on the MVME162LX is a 32-bit synchronous bus that is based on the MC68040 bus, and which supports burst transfers and snooping. The various local bus master and slave devices use the local bus to communicate. The local bus is arbitrated by priority type arbiter and the priority of the local bus masters from highest to lowest is: 82596CA LAN, 53C710 SCSI, VMEbus, and MPU. In the general case, any master can access any slave; however, not all combinations pass the common sense test. Refer to the *MVME162LX Embedded Controller Programmer's Reference Guide* and to the user's guide for each device to determine its port size, data bus connection, and any restrictions that apply when accessing the device.

## Microprocessor

The MVME162LX is built with a 32MHz MC68040 microprocessor.

The MC68040 has on-chip instruction and data caches, optional high drive I/O buffers, and a floating point processor. The MC68040 supports cache coherency in multi-master applications with dedicated on-chip bus snooping logic. Refer to the M68040 reference manual for detailed information.

## MC68040 Cache

The MVME162LX local bus masters (VMEchip2, MC68040, 53C710 SCSI controller, and 82596CA Ethernet controller) have programmable control of the snoop/caching mode. The IP DMA local bus master's snoop control function is controlled by jumper settings at J19. J19 controls the state of the snoop control signals for all IP DMA transfers (including the IP DMA which is executed when the DMA control registers are updated during IP DMA operation in the command chaining mode). The MVME162LX local bus slaves that support MC68040 bus snooping are defined in the Local Bus Memory Map table later in this chapter.

## No-VMEbus-Interface Option

The 700/800-series MVME162LX may be operated as an embedded controller without the VMEbus interface. For this option, the VMEchip2 ASIC and the VMEbus buffers are not populated. Also, the bus grant daisy chain and the interrupt acknowledge daisy chain have zero-ohm bypass resistors installed.

To support this feature, certain logic in the VMEchip2 has been duplicated in the MC2chip. This logic is inhibited in the MC2chip when the VMEchip2 is present. The enables for these functions are controlled by software and MC2chip hardware initialization.

Note that MVME162LX models ordered without the VMEbus interface are shipped with Flash memory blank (the factory uses the VMEbus to program the Flash memory with debugger code). To use the 162Bug package, MVME162Bug, be sure that jumper header J21 is configured for the EPROM memory map. Refer to Chapters 2 and 3 for further details.

Contact your local Motorola sales office for ordering information.

## Memory Options

The following memory options are used on the different versions of 700/800-series MVME162LX boards.

### DRAM Options

The MVME162LX offers the following DRAM options:

- ❑ 4, 8, or 16MB shared DRAM with programmable parity on a mezzanine module
- ❑ 4, 8, 16, or 32MB ECC DRAM on a mezzanine module

The DRAM architecture for non-ECC memory is non-interleaved for 4 or 8MB and interleaved for 16MB. Parity protection is enabled with interrupts or bus exception when a parity error is detected.

DRAM performance is specified in the section on the DRAM Memory Controller in the MC2chip Programming Model in the *MVME162LX Embedded Controller Programmer's Reference Guide*.

The DRAM map decoder may be programmed to accommodate different base address(es) and sizes of mezzanine boards. The onboard DRAM is disabled by a local bus reset and must be programmed before the DRAM may be accessed. Refer to the MC2chip and MCECC descriptions in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

Most DRAM devices require some number of access cycles before the DRAMs are fully operational. Normally this requirement is met by the onboard refresh circuitry and normal DRAM initialization. However, software should insure a minimum of 10 initialization cycles are performed to each bank of RAM.

## **SRAM Options**

The MVME162LX provides 128KB of 32-bit-wide onboard static RAM in a single non-interleaved architecture with onboard battery backup. The SRAM arrays are not parity protected.

The SRAM battery backup function is provided by a Dallas DS1210S device. The DS1210S supports primary and secondary power sources. When the main board power fails, the DS1210S selects the source with the higher voltage. If one source should fail, the DS1210S switches to the redundant source. Each time the board is powered up, the DS1210S checks power sources and if the voltage of the backup source is less than two volts, the second memory cycle is blocked. This allows software to provide an early warning to avoid data loss. Because the DS1210S may block the second access, software should do at least two accesses before relying on the data.

The MVME162LX provides jumpers (on J14) that allow either power source of the DS1210S to be connected to the VMEbus +5V STDBY pin or to one cell of the onboard battery. For example, the primary system backup source may be a battery connected to the

VMEbus +5V STDBY pin and the secondary source may be the onboard battery. If the system source should fail or the board is removed from the chassis, the onboard battery takes over. Refer to Chapter 2 for the jumper configurations.

**Caution**

For proper operation of the SRAM, some jumper combination must be installed on the respective Backup Power Source Select Header (J14). If one of the jumpers is used to select the battery, the battery must be installed on the MVME162LX. The SRAM may malfunction if inputs to the DS1210S are left unconnected.

The SRAM is controlled by the MC2chip, and the access time is programmable. Refer to the MC2chip description in the *MVME162LX Embedded Controller Programmer's Reference Guide* for more detail.

**About the Battery**

The power source for the onboard SRAM is a RAYOVAC FB1225 battery with two BR1225-type lithium cells which is socketed for easy removal and replacement. A small capacitor is provided to allow the battery to be quickly replaced without data loss.

The lifetime of the battery is very dependent on the ambient temperature of the board and the power-on duty cycle. The lithium battery supplied on the MVME162LX should provide at least two years of backup time with the board powered off and with an ambient temperature of 40° C. If the power-on duty cycle is 50% (the board is powered on half of the time), the battery lifetime is four years. At lower ambient temperatures, the backup time is greatly extended.

When a board is stored, the battery should be disconnected to prolong battery life. This is especially important at high ambient temperatures. The MVME162LX is shipped with the batteries disconnected (i.e., with VMEbus +5V standby voltage selected as both primary and secondary power source). If you intend to use the

battery as a power source, whether primary or secondary, it is necessary to reconfigure the jumpers on J14 before installing the board. Refer to *SRAM Backup Power Source Select Header (J14)* on page 2-6 for available jumper configurations

The power leads from the battery are exposed on the solder side of the board. The board should not be placed on a conductive surface or stored in a conductive bag unless the battery is removed.



Lithium batteries incorporate inflammable materials such as lithium and organic solvents. If lithium batteries are mistreated or handled incorrectly, they may burst open and ignite, possibly resulting in injury and/or fire. When dealing with lithium batteries, carefully follow the precautions listed below in order to prevent accidents.

- ❑ Do not short circuit.
- ❑ Do not disassemble, deform, or apply excessive pressure.
- ❑ Do not heat or incinerate.
- ❑ Do not apply solder directly.
- ❑ Do not use different models, or new and old batteries together.
- ❑ Do not charge.
- ❑ Always check proper polarity.

To remove the battery from the module, carefully pull the battery from the socket (BT1, shown in [Figure 2-1](#)).

Before installing a new battery, ensure that the battery pins are clean. Note the battery polarity and press the battery into the socket. No soldering is required.

## EPROM and Flash Memory

The MVME162LX may be ordered with 2MB of Flash memory and two EPROM sockets ready for the installation of the EPROMs, which may be ordered separately. Flash memory is a single Intel 28F016SA device organized in a 2Mbit x 8 configuration. The EPROM locations are standard JEDEC 32-pin DIP sockets that accommodate three jumper-selectable densities (256 Kbit x 8; 512 Kbit x 8, the factory default; 1 Mbit x 8). A jumper setting (GPI3, pins 7-8 on J21), allows reset code to be fetched either from Flash memory (GPI3 installed) or from EPROMs (GPI3 removed).

## Battery Backed Up RAM and Clock

An M48T58 RAM and clock chip is used on the MVME162LX. This chip provides a time-of-day clock, oscillator, crystal, power fail detection, memory write protection, 8KB of RAM, and a battery in one 28-pin package. The clock provides seconds, minutes, hours, day, date, month, and year in BCD 24-hour format. Corrections for 28-, 29- (leap year), and 30-day months are automatically made. No interrupts are generated by the clock. Although the M48T58 is an 8 bit device, the interface provided by the MC2chip supports 8-, 16-, and 32-bit accesses to the M48T58. Refer to the MC2chip in the *MVME162LX Embedded Controller Programmer's Reference Guide* and to the M48T58 data sheet for detailed programming and battery life information.

## VMEbus Interface and VMEchip2

The optional VMEchip2 provides the local-bus-to-VMEbus interface, the VMEbus-to-local-bus interface, and the DMA controller functions of the local VMEbus. The VMEchip2 also provides the VMEbus system controller functions. Refer to the VMEchip2 description in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

Note that the ABORT switch logic in the VMEchip2 is not used. The GPI inputs to the VMEchip2 which are located at \$FFF40088 bits 7-0 are not used. The ABORT switch interrupt is integrated into the MC2chip ASIC at location \$FFF42043. The GPI inputs are integrated into the MC2chip ASIC at location \$FFF4202C bits 23-16.

## I/O Interfaces

The MVME162LX provides onboard I/O for many system applications. The I/O functions include serial ports, IndustryPack (IP) interfaces, an optional LAN Ethernet transceiver interface, and an optional SCSI mass storage interface.

### Serial Communications Interface

The MVME162LX uses two Zilog Z85230 serial port controllers to implement the four serial communications interfaces. Each interface supports CTS, DCD, RTS, and DTR control signals, as well as the TXD and RXD transmit/receive data signals. Because the serial clocks are omitted in the MVME162LX implementation, serial communications are strictly asynchronous. The MVME162LX hardware supports serial baud rates of 110b/s to 38.4Kb/s.

The Z85230 supplies an interrupt vector during interrupt acknowledge cycles. The vector is modified based upon the interrupt source within the Z85230. Interrupt request levels are programmed via the MC2chip. Refer to the Z85230 data sheet listed in this chapter, and to the MC2chip Programming Model in the *MVME162LX Embedded Controller Programmer's Reference Guide*, for information.

The Z85230s are interfaced as DTE (data terminal equipment) with EIA-232-D signal levels. The four serial ports are routed to four RJ-45 connectors on the MVME162LX front panel.



## IndustryPack (IP) Interfaces

Up to two IP modules may be installed on the 700/800-series MVME162LX as an option. The interface between the IPs and MVME162LX is the IndustryPack Interface Controller (IP2) ASIC. Access to the IPs is provided by two 3M connectors located behind the MVME162LX front panel. Refer to the chapter on the IP2 in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed features of the IP interface.

## Optional Ethernet Interface

The MVME162LX uses the 82596CA to implement the Ethernet transceiver interface. The 82596CA accesses local RAM using DMA operations to perform its normal functions. Because the 82596CA has small internal buffers and the VMEbus has an undefined latency period, buffer overrun may occur if the DMA is programmed to access the VMEbus. Therefore, the 82596CA should not be programmed to access the VMEbus.

Every MVME162LX that has the Ethernet interface is assigned an Ethernet Station Address. The address is \$08003E2XXXXX where XXXXX is the unique 5-nibble number assigned to the board (i.e., every MVME162LX has a different value for XXXXX).

Each board has an Ethernet Station Address displayed on a label attached to the VMEbus P2 connector. In addition, the six bytes including the Ethernet address are stored in the configuration area of the BBRAM. That is, 08003E2XXXXX is stored in the BBRAM. The upper four bytes (08003E2X) are read at \$FFFC1F2C; the lower two bytes (XXXX) are read at \$FFFC1F30. The debugger firmware has the capability to retrieve or set the Ethernet address.

If the data in the BBRAM is lost, use the number on the label on backplane connector P2 to restore it.

The Ethernet transceiver interface is located on the MVME162LX main board, and the industry standard connector is located on its front panel.

Support functions for the 82596CA are provided by the MC2chip. Refer to the 82596CA user's guide and to the MC2chip description in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

### **Optional SCSI Interface**

The MVME162LX supports mass storage subsystems through the industry-standard SCSI bus. These subsystems may include hard and floppy disk drives, streaming tape drives, and other mass storage devices. The SCSI interface is implemented using the NCR 53C710 SCSI I/O controller.

Support functions for the 53C710 are provided by the MC2chip. Refer to the NCR 53C710 user's guide and to the MC2chip description in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

### **SCSI Termination**

It is important that the SCSI bus be properly terminated at both ends.

The MVME162LX main board provides terminators for the SCSI bus. The SCSI terminators are enabled / disabled by a jumper on header J12. If the SCSI bus ends at the MVME162LX, a jumper must be installed between J12 pins 1 and 2.

The FUSES LED (part of DS2) on the MVME162LX front panel monitors the SCSI bus TERMPWR signal in addition to LAN power and IndustryPack power; the FUSES LED lights when all fuses are operational. The fuses are solid-state devices that reset when the short is removed.

Because any device on the SCSI bus can provide TERMPWR, the FUSES LED does not directly indicate the condition of the fuse.

## Local Resources

The MVME162LX includes many resources for the local processor. These include tick timers, software-programmable hardware interrupts, watchdog timer, and local bus timeout.

### Programmable Tick Timers

Six 32-bit programmable tick timers with 1 $\mu$ s resolution are provided, four in the MC2chip and two in the optional VMEchip2. The tick timers may be programmed to generate periodic interrupts to the processor. Refer to the VMEchip2 and MC2chip descriptions in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

### Watchdog Timer

A watchdog timer function is provided in both the MC2chip and the optional VMEchip2. The timers operate independently but in parallel. When the watchdog timers are enabled, they must be reset by software within the programmed time or they will time out. The watchdog timers may be programmed to generate a SYSRESET signal, local reset signal, or board fail signal if they time out. Refer to the VMEchip2 and MC2chip descriptions in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

The watchdog timer logic is duplicated in the VMEchip2 and MC2chip ASICs. Because the watchdog timer function in the VMEchip2 is a superset of that function in the MC2chip (system reset function), the timer in the VMEchip2 is used in all cases except for the version of the MVME162LX which does not include the VMEbus interface (described under "No-VMEbus-Interface option").

## Software-Programmable Hardware Interrupts

Eight software-programmable hardware interrupts are provided by the VMEchip2. These interrupts allow software to create a hardware interrupt. Refer to the VMEchip2 description in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

## Local Bus Timeout

The MVME162LX provides a timeout function in the VMEchip2 and the MC2chip for the local bus. When the timer is enabled and a local bus access times out, a Transfer Error Acknowledge (TEA) signal is sent to the local bus master. The timeout value is software-selectable for 8  $\mu$ sec, 64  $\mu$ sec, 256  $\mu$ sec, or infinity. The local bus timer does not operate during VMEbus bound cycles. VMEbus bound cycles are timed by the VMEbus access timer and the VMEbus global timer. Refer to the VMEchip2 and the MC2chip descriptions in the *MVME162LX Embedded Controller Programmer's Reference Guide* for detailed programming information.

The MC2chip also provides local bus timeout logic for MVME162LXs without the optional VMEbus interface (i.e., without the VMEchip2 ASIC).

The access timer logic is duplicated in the VMEchip2 and MC2chip ASICs. Because the local bus timer in the VMEchip2 can detect an offboard access and the MC2chip local bus timer cannot, the timer in the VMEchip2 is used in all cases except for the version of the MVME162LX which does not include the VMEbus interface (described under "No-VMEbus-Interface option").

## Local Bus Arbiter

The local bus arbiter implements a fixed priority, which is described in the following table.

**Table 1-3. Local Bus Arbitration Priority**

Device	Priority	Note
LAN	0	Highest
IndustryPack DMA	1	
SCSI	2	...
VMEbus	3	Next lowest
MC68040		

## Connectors

The MVME162LX has two 96-position DIN connectors: P1 and P2. P1 rows A, B, C, and P2 row B provide the VMEbus interconnection. P2 rows A and C are not used.

The MVME162LX has a 20-pin connector J2 mounted behind the front panel. When the MVME162LX board is enclosed in a chassis and the front panel is not visible, this connector allows the reset, abort and LED functions to be extended to the control panel of the system, where they are visible.

The serial ports on the MVME162LX are connected to four 8-pin RJ-45 female connectors (J17) on the front panel. The two IPs connect to the MVME162LX by two pairs of 50-pin connectors. Two 50-pin connectors behind the front panel are for external connections to IP signals. The memory mezzanine board is plugged into two 100-pin connectors. The Ethernet LAN connector (J9) is a 15-pin socket connector mounted on the front panel. The SCSI connector (J23) is a 68-pin socket connector mounted on the front panel.

## Memory Maps

There are two points of view for memory maps: 1) the mapping of all resources as viewed by local bus masters (local bus memory map), and 2) the mapping of onboard resources as viewed by external masters (VMEbus memory map).

The memory and I/O maps that are described in the next three tables are correct for all local bus masters. There is some address translation capability in the VMEchip2. This allows multiple MVME162LXs on the same VMEbus with different virtual local bus maps as viewed by different VMEbus masters.

### Local Bus Memory Map

The local bus memory map is split into different address spaces by the transfer type (TT) signals. The local resources respond to the normal access and interrupt acknowledge codes.

#### Normal Address Range

The memory map of devices that respond to the normal address range is shown in the following tables. The normal address range is defined by the Transfer Type (TT) signals on the local bus. On the MVME162LX, Transfer Types 0, 1, and 2 define the normal address range. [Table 1-4](#) is the entire map from \$00000000 to \$FFFFFFFF. Many areas of the map are user-programmable, and suggested uses are shown in the table. The cache inhibit function is programmable in the MC68040 MMU (memory management unit). The onboard

I/O space must be marked cache inhibit and serialized in its page table. [Table 1-5 on page 1-31](#) further defines the map for the local I/O devices.

**Table 1-4. Local Bus Memory Map**

Address Range	Devices Accessed	Port Width	Size	Software Cache Inhibit	Notes
Programmable	DRAM on parity mezzanine	D32	4MB-16MB	N	2
Programmable	DRAM on ECC mezzanine	D32	4MB-32MB	N	2
Programmable	Onboard SRAM	D32	128KB	N	2
Programmable	VMEbus A32/A24	D32-D16	--	?	4
Programmable	IP_a memory	D32-D8	64KB-8MB	?	2, 4
Programmable	IP_b memory	D32-D8	64KB-8MB	?	2, 4
\$FF800000-\$FF9FFFFF	Flash/EEPROM	D32	2MB	N	1, 5
\$FFA00000-\$FFBFFFFF	EPRAM/Flash	D32	2MB	N	5
\$FFC00000-\$FFDFFFFF	Not decoded	D32	2MB	N	
\$FFE00000-\$FFE1FFFF	Onboard SRAM default	D32	128KB	N	

**Table 1-4. Local Bus Memory Map (Continued)**

Address Range	Devices Accessed	Port Width	Size	Software Cache Inhibit	Notes
\$FFE80000-\$FFEFFFFFFF	Not decoded	--	512KB	N	6
\$FFF00000-\$FFFFFFFFFF	Local I/O devices (see next table)	D32-D8	878KB	Y	3
\$FFFF0000-\$FFFFFFFF	VMEbus A16	D32/D16	64KB	?	2, 4

**Notes**

1. Devices mapped at \$FFF80000-\$FFF9FFFF also appear at \$00000000-\$001FFFFFFF when the ROM0 bit in the MC2chip EPROM control register is high (ROM0=1). ROM0 is set to 1 after each reset. The ROM0 bit must be cleared before other resources (DRAM or SRAM) can be mapped in this range (\$00000000 - \$001FFFFFFF).

The EPROM/Flash memory map is also controlled by the EPROM size and by control bit V19 in the MC2chip ASIC. Refer to the EPROM/Flash configuration tables in the *MVME162LX Embedded Controller Programmer's Reference Guide* for further details.

2. This area is user-programmable. The DRAM and SRAM decoder is programmed in the MC2chip, the local-to-VMEbus decoders are programmed in the VMEchip2, and the IP memory space is programmed in the IP2.
3. Size is approximate.
4. Cache inhibit depends on the devices in the area mapped.
5. The EPROM and Flash are dynamically sized by the MC2chip ASIC from an 8-bit private bus to the 32-bit MPU local bus.
6. These areas are not decoded unless one of the programmable decoders is initialized to decode this space. If they are not decoded and the local timer is enabled, an access to this address range will generate a local bus timeout.

The next table describes the "Local I/O Devices" portion of the local bus main memory map.



**Note** The IP2 chip on the MVME162LX supports up to four IP interfaces, designated IP\_a through IP\_d. The 700/800-series MVME162LX itself accommodates two IPs: IP\_a and IP\_b. In the following map, the segments applicable to IP\_c and IP\_d are not used in the 700/800-series MVME162LX.

**Table 1-5. Local I/O Devices Memory Map**

Address Range	Devices Accessed	Port Width	Size	Notes
\$FFF00000 - \$FFF3FFFF	Reserved	--	256KB	4
\$FFF40000 - \$FFF400FF	VMEchip2 (LCSR)	D32	256B	1, 3
\$FFF40100 - \$FFF401FF	VMEchip2 (GCSR)	D32-D8	256B	1, 3
\$FFF40200 - \$FFF40FFF	Reserved	--	3.5KB	4, 5
\$FFF41000 - \$FFF41FFF	Reserved	--	4KB	4
\$FFF42000 - \$FFF42FFF	MC2chip	D32-D8	4KB	1
\$FFF43000 - \$FFF430FF	MCECC #1	D8	256B	1, 8
\$FFF43100 - \$FFF431FF	MCECC #2	D8	256B	1, 8
\$FFF43200 - \$FFF43FFF	MCECCs (repeated)	--	3.5KB	1, 5, 8
\$FFF44000 - \$FFF44FFF	Reserved	--	8KB	4
\$FFF45000 - \$FFF457FF	SCC #1 (Z85230)	D8	2KB	1, 2
\$FFF45800 - \$FFF45FFF	SCC #2 (Z85230)	D8	2KB	1, 2
\$FFF46000 - \$FFF46FFF	LAN (82596CA)	D32	4KB	1, 6
\$FFF47000 - \$FFF47FFF	SCSI (53C710)	D32-D8	4KB	1
\$FFF48000 - \$FFF57FFF	Reserved	--	64KB	4
\$FFF58000 - \$FFF5807F	IP2 IP_a I/O	D16	128B	1
\$FFF58080 - \$FFF580FF	IP2 IP_a ID	D16	128B	1
\$FFF58100 - \$FFF5817F	IP2 IP_b I/O	D16	128B	1
\$FFF58180 - \$FFF581FF	IP2 IP_b ID Read	D16	128B	1

**Table 1-5. Local I/O Devices Memory Map (Continued)**

Address Range	Devices Accessed	Port Width	Size	Notes
\$FFF58200 - \$FFF5827F	IP2 IP_c I/O	D16	128B	7
\$FFF58280 - \$FFF582FF	IP2 IP_c ID	D16	128B	7
\$FFF58300 - \$FFF5837F	IP2 IP_d I/O	D16	128B	7
\$FFF58380 - \$FFF583FF	IP2 IP_d ID Read	D16	128B	7
\$FFF58400 - \$FFF584FF	IP2 IP_ab I/O	D32-D16	256B	1
\$FFF58500 - \$FFF585FF	IP2 IP_cd I/O	D32-D16	256B	7
\$FFF58600 - \$FFF586FF	IP2 IP_ab I/O Repeated	D32-D16	256B	1
\$FFF58700 - \$FFF587FF	IP2 IP_cd I/O Repeated	D32-D16	256B	7
\$FFF58800 - \$FFF5887F	Reserved	--	128B	1
\$FFF58880 - \$FFF588FF	Reserved	--	128B	1
\$FFF58900 - \$FFF5897F	Reserved	--	128B	1
\$FFF58980 - \$FFF589FF	Reserved	--	128B	1
\$FFF58A00 - \$FFF58A7F	Reserved	--	128B	1
\$FFF58A80 - \$FFF58AFF	Reserved	--	128B	1
\$FFF58B00 - \$FFF58B7F	Reserved	--	128B	1
\$FFF58B80 - \$FFF58BFF	Reserved	--	128B	1
\$FFF58C00 - \$FFF58CFF	Reserved	--	256B	1
\$FFF58D00 - \$FFF58DFF	Reserved	--	256B	1
\$FFF58E00 - \$FFF58EFF	Reserved	--	256B	1
\$FFF58F00 - \$FFF58FFF	Reserved	--	256B	1
\$FFFBC000 - \$FFFBC01F	IP2 Registers	D32-D8	2KB	1
\$FFFBC800 - \$FFFBC81F	Reserved	--	2KB	1

**Table 1-5. Local I/O Devices Memory Map (Continued)**

Address Range	Devices Accessed	Port Width	Size	Notes
\$FFFBD000 - \$FFFBFFFF	Reserved	--	12KB	4
\$FFFC0000 - \$FFFCFFFF	M48T58 (BBRAM, TOD Clock)	D32-D8	64KB	1, 9
\$FFFD0000 - \$FFFEFFFF	Reserved	--	128KB	4
<p>Notes</p> <ol style="list-style-type: none"> <li>For a complete description of the register bits, refer to the data sheet for the specific chip. For a more detailed memory map, refer to the <i>MVME162LX Embedded Controller Programmer's Reference Guide</i>.</li> <li>The SCC is an 8-bit device located on an MC2chip private data bus. Byte access is required.</li> <li>Writes to the LCSR in the VMEchip2 must be 32 bits. LCSR writes of 8 or 16 bits terminate with a TEA signal. Writes to the GCSR may be 8, 16 or 32 bits. Reads to the LCSR and GCSR may be 8, 16 or 32 bits. Byte reads should be used to read the interrupt vector.</li> <li>This area does not return an acknowledge signal. If the local bus timer is enabled, the access times out and is terminated by a TEA signal.</li> <li>Size is approximate.</li> <li>Port commands to the 82596CA must be written as two 16-bit writes: upper word first and lower word second.</li> <li>Not used.</li> <li>To use this area, the ECC mezzanine board must be installed. If it is not installed, no acknowledge signal is returned; if the local bus timer is enabled, the access times out and is terminated by a TEA signal.</li> <li>Repeats on 8KB boundaries.</li> </ol>				

## VMEbus Memory Map

This section describes the mapping of local resources as viewed by VMEbus masters. Default addresses for the slave, master, and GCSR address decoders are provided by the **ENV** command. Refer to Appendix A.

### VMEbus Accesses to the Local Bus

The VMEchip2 includes a user-programmable map decoder for the VMEbus-to-local-bus interface. The map decoder allows you to program the starting and ending address and the modifiers that the MVME162LX responds to.

### VMEbus Short I/O Memory Map

The VMEchip2 includes a user-programmable map decoder for the GCSR. The GCSR map decoder allows you to program the starting address of the GCSR in the VMEbus short I/O space.

# Hardware Preparation and Installation

# 2

## Introduction

This chapter provides unpacking instructions, hardware preparation guidelines, and installation instructions for the 700/800-series MVME162LX VME Embedded Controller.

## Unpacking Instructions

**Note** If the shipping carton is damaged upon receipt, request that the carrier's agent be present during the unpacking and inspection of the equipment.

Unpack the equipment from the shipping carton. Refer to the packing list and verify that all items are present. Save the packing material for storing and reshipping of equipment.



**Caution**

Avoid touching areas of integrated circuitry; static discharge can damage circuits.

## Hardware Preparation

To select the desired configuration and ensure proper operation of the MVME162LX, certain option modifications may be necessary before installation. The MVME162LX provides software control for most of these options. Some options cannot be modified in software, and consequently are set by installing or removing jumpers on headers. Most other modifications are performed by setting bits in control registers after the MVME162LX has been installed in a system. (The MVME162LX registers are described in

Chapter 4, and/or in the *MVME162FX Embedded Controller Programmer's Reference Guide* as listed in *Related Documentation* in Chapter 1.)

Figure 2-1 illustrates the placement of the switches, jumper headers, connectors, and LED indicators on the MVME162LX. Manually configurable items on the board are listed in the following table. Default settings are enclosed in brackets.

**Table 2-1. Jumper Settings**


Jumper	Function	Settings	
J1	System controller selection	No jumper [1-2] 2-3	Not system controller. System controller. Auto system controller.
J11	IP bus clock selection	[1-2] 2-3	8MHz clock. 32MHz clock.
J12	SCSI termination	No jumper [1-2]	Onboard terminators disabled. Onboard terminators enabled.
J14	SRAM backup power source selection	No jumper [1-3, 2-4] 3-5, 4-6 1-3, 4-6 3-5, 2-4	Backup power disabled. Primary : VMEbus +5V STBY — secondary : VMEbus +5V STBY. Primary : onboard battery — secondary : onboard battery. Primary : VMEbus +5V STBY — secondary : onboard battery. Primary : onboard battery — secondary : VMEbus +5V STBY.
J16	Flash write protection	[No jumper] 1-2	Flash write protection on (writes disabled). Flash write protection off (writes enabled).
J18	IP bus strobe selection	No jumper [1-2]	Strobe disconnected. Strobe connected.
J19	IP DMA snoop selection	1-2, no jumper [1-2, 3-4]	Snoop enabled (pins 1-2 = don't care). Snoop inhibited.
J20	EPROM/Flash configuration	3-4, 9-11, 10-12 [5-6, 9-11, 8-10] 7-9, 8-10 1-2, 7-9, 8-10	256K x 8 EPROMs. 512K x 8 EPROMs. 1M x 8 EPROMs. 1M x 8 EPROMs (on-board Flash disabled).
J21	General-purpose readable jumper configuration	[No jumper] 7-8	EPROM selected. Flash selected. Other headers are user-definable (see description).

MVME162LX embedded controllers are factory tested and shipped with the default configurations listed above and described in the following sections. The MVME162LX's required and factory-installed debug monitor, MVME162Bug (162Bug), operates with those factory settings.

## System Controller Select Header (J1)

The MVME162LX is factory-configured as a VMEbus system controller by a jumper across J1 pins 1 and 2. If you select the "automatic" system controller function by moving the jumper to J1 pins 2 and 3, the MVME162LX determines whether it is the system controller by its position on the bus. If the board is in the first slot from the left, it configures itself as the system controller. If the MVME162LX is not to be system controller under any circumstances, remove the jumper from J1. When the board is functioning as system controller, the SCON LED is turned on.

**Note** For MVME162LXs without the optional VMEbus interface (i.e., with no VMEchip2), the jumper may be installed or removed without affecting normal operation.






Figure 2-1. MVME162LX Board Layout





## IP Bus Clock Header (J11)

J11 selects the speed of the IP bus clock. You can either set the IP bus clock to 8MHz or allow it to match the the local bus clock, which is 32MHz for the MC68040. The factory configuration has a jumper between J11 pins 1 and 2 for an 8MHz clock.

If the jumper is installed between J11 pins 2 and 3, the IP bus clock speed is the same as that of the MC68040 bus clock, that is 32MHz, allowing the IP module to run with a 32MHz MPU. Regardless of the IP bus clock setting, all IP ports operate at the same speed.




The IP32 CSR bit (IP2 chip, register at offset \$1D, bit 0) must be set to correspond to the jumper setting. This is cleared (0) for 8MHz, or set (1) for 32MHz. If the jumper and the bit are not configured the same, the board may not run properly.



## SCSI Terminator Enable Header (J12)

The MVME162LX provides terminators for the SCSI bus. The SCSI terminators are enabled/disabled by a jumper on header J12. The SCSI terminators may be configured as follows.



**Note** If the MVME162LX is to be used at one end of the SCSI bus, the SCSI bus terminators must be enabled.

## SRAM Backup Power Source Select Header (J14)


Header J14 determines the source for onboard static RAM backup power on the MVME162LX.

The following backup power configurations are available for onboard SRAM through header J14. In the factory configuration, the VMEbus +5V standby voltage serves as primary and secondary power source (the onboard battery is disconnected).

**Note** For MVME162LXs without the optional VMEbus interface (i.e., without the VMEchip2 ASIC), you must select the onboard battery as the backup power source.




Removing all jumpers may temporarily disable the SRAM. Do not remove all jumpers from J14, except for storage.



## Flash Write Protect Header (J16)

The firmware resident in Flash memory is originally loaded at the factory, but the Flash contents can be reprogrammed if necessary. To prevent inadvertent overwriting of the Flash memory, header J16 provides write protection. With a jumper installed on J16, the Flash memory can be written to via normal software routines. When the jumper is removed (the factory configuration), Flash memory cannot be written to.




## IP Bus Strobe Select Header (J18)

Some IP bus implementations make use of the Strobe\* signal (pin 46) as an input to the IP modules from the IP2 chip. Other IP interfaces require that the strobe be disconnected.


With a jumper installed between J18 pins 1 and 2, a programmable frequency source is connected to the Strobe\* signal on the IP bus (for details, refer to the IP2 chip programming model in the *MVME162LX Embedded Controller Programmer's Reference Guide*).

If the jumper is removed from J18, the strobe line is available for a sideband type of messaging between IP modules. The Strobe\* signal is not connected to any active devices on the board, but it may be connected to a pull-up resistor.



## IP DMA Snoop Control Header (J19)

The jumpers on header J19 define the state of the snoop control bus when an IP DMA controller is local bus master. Placing a jumper on J19 pins 3 to 4 inhibits snooping (the snoop signal to the MC68040 is driven low during IP DMA). Leaving pins 3 and 4 unconnected enables snooping. Pins 1 and 2 are not used for the MC68040.



The following table lists the snoop operations represented by the setting of J19.

**Table 2-2. J19 Snoop Control Encoding**

Pins 1-2	Pins 3-4	Snoop Operation
X	0	Snoop disabled
X	1	Snoop enabled

X = don't care

Jumper installed = logic 0

Jumper removed = logic 1

## EPROM/Flash Configuration Header (J20)

The MVME162LX can be ordered with 2MB of Flash memory and two EPROM sockets ready for the installation of the EPROMs, which may be ordered separately. The EPROM locations are standard JEDEC 32-pin DIP sockets. The EPROM sockets accommodate three jumper-selectable densities (256 Kbit x 8; 512 Kbit x 8 — the default configuration; 1 Mbit x 8) and permit disabling of the Flash memory.

Header J20 provides eight jumper locations to configure the EPROM sockets.



**Table 2-3. EPROM/Flash Mapping — 256K x 8 EPROMs**

GPI3		Address Range	Device Accessed
Removed	1	\$FF800000 - \$FF83FFFF	EPROM A (XU1)
		\$FF840000 - \$FF87FFFF	EPROM B (XU2)
		\$FFA00000 - \$FFBFFFFFFF	Onboard Flash
Installed	0	\$FF800000 - \$FF9FFFFFFF	Onboard Flash
		\$FFA00000 - \$FFA3FFFF	EPROM A (XU1)
		\$FFA40000 - \$FFA7FFFF	EPROM B (XU2)

**Table 2-4. EPROM/Flash Mapping — 512K x 8 EPROMs**

GPI3		Address Range	Device Accessed
Removed	1	\$FF800000 - \$FF87FFFF	EPROM A (XU1)
		\$FF880000 - \$FF8FFFFFFF	EPROM B (XU2)
		\$FFA00000 - \$FFBFFFFFFF	Onboard Flash
Installed	0	\$FF800000 - \$FF9FFFFFFF	Onboard Flash
		\$FFA00000 - \$FFA7FFFF	EPROM A (XU1)
		\$FFA80000 - \$FFAFFFFF	EPROM B (XU2)

**Table 2-5. EPROM/Flash Mapping — 1M x 8 EPROMs**

GPI3		Address Range	Device Accessed
Removed	1	\$FF800000 - \$FF8FFFFFFF	EPROM A (XU1)
		\$FF900000 - \$FF9FFFFFFF	EPROM B (XU2)
		\$FFA00000 - \$FFBFFFFFFF	Onboard Flash
Installed	0	\$FF800000 - \$FF9FFFFFFF	Onboard Flash
		\$FFA00000 - \$FFAFFFFF	EPROM A (XU1)
		\$FFB00000 - \$FFBFFFFFFF	EPROM B (XU2)

**Table 2-6. EPROM/Flash Mapping — 1M x 8 EPROMs, Onboard Flash Disabled**

GPI3		Address Range	Device Accessed
Removed	1	\$FF800000 - \$FF8FFFFFFF	EPROM A (XU1)
		\$FF900000 - \$FF9FFFFFFF	EPROM B (XU2)
		Not used	Onboard Flash
Installed	0	Not used	Onboard Flash
		\$FF800000 - \$FF8FFFFFFF	EPROM A (XU1)
		\$FF900000 - \$FF9FFFFFFF	EPROM B (XU2)

## General-Purpose Readable Jumpers Header (J21)

Header J21 provides eight readable jumpers. These jumpers are read as a register (at \$FFF4202D) in the MC2chip LCSR (local control/ status register). The bit values are read as a 0 when the jumper is installed, and as a 1 when the jumper is removed.

With the factory-installed MVME162BUG firmware in place, four jumpers are user-definable (pins 9-10, 11-12, 13-14, 15-16). If the MVME162BUG firmware is removed, seven jumpers are user-definable (i.e., pins 1-2, 3-4, 5-6, 9-10, 11-12, 13-14, 15-16).

**Note** Pins 7-8 (GPI3) are reserved to select either the Flash memory map (jumper installed) or the EPROM memory map (jumper removed). They are not user-definable. The address ranges for the various EPROM/Flash configurations appear in the section on header J20.

In most cases, the MVME162LX is shipped from the factory with J21 set to all zeros (jumpers on all pins) except for GPI3 (pins 7-8). *On boards built with the no-VMEbus option, however, GPI3 is jumpered as well.*



		J21	162BUG INSTALLED	USER CODE INSTALLED
GPI7	15	████████	16 USER-DEFINABLE	USER-DEFINABLE
GPI6		████████	USER-DEFINABLE	USER-DEFINABLE
GPI5		████████	USER-DEFINABLE	USER-DEFINABLE
GPI4		████████	USER-DEFINABLE	USER-DEFINABLE
GPI3	7	<input type="checkbox"/> <input type="checkbox"/>	8 IN=FLASH; OUT=EPROM	IN=FLASH; OUT=EPROM
GPI2		████████	REFER TO 162BUG MANUAL	USER-DEFINABLE
GPI1		████████	REFER TO 162BUG MANUAL	USER-DEFINABLE
GPI0	1	████████	2 REFER TO 162BUG MANUAL	USER-DEFINABLE

EPROMs Selected (factory configuration except on no-VMEbus models)

## Memory Mezzanine Options

The 700/800-series MVME162LX has two 100-pin connectors (J15 and J22) to accommodate optional memory mezzanine boards. Two memory mezzanine options are available:

- 4/8/16MB parity DRAM
- 4/8/16/32MB ECC DRAM

The mezzanine boards may either be used individually or be combined in a stack (not more than two deep). The following connector options govern stacking arrangements:

- The 4/8/16MB parity DRAM board has connectors on the bottom only; it must be either the only mezzanine or the top mezzanine.
- All ECC DRAM boards have two connector options:
  - Connectors top and bottom for stackability
  - Connectors on the bottom only; must be either the only mezzanine or the top mezzanine

When the mezzanines are stacked, the following combinations are possible:

**Table 2-7. Memory Mezzanine Stacking Options**

<b>Upper Mezzanine</b>	None	None	Parity DRAM	ECC DRAM
<b>Lower Mezzanine</b>	Parity DRAM	ECC DRAM	ECC DRAM	ECC DRAM

**Note** When equipped with a single memory mezzanine, MVME162LX VME modules maintain a single VME slot width. With two memory mezzanines, the MVME162LX extends into the adjacent VME slot. The latter versions have double-wide front panels.

## Installation Instructions

This section covers:

- ❑ Installation of IndustryPacks (IPs) on the MVME162LX
- ❑ Installation of the MVME162LX in a VME chassis
- ❑ System considerations relevant to the installation.

Before installing IndustryPacks, ensure that EPROM devices are installed as needed and that all header jumpers are configured as desired.

## IP Installation on the MVME162LX

Up to two IPs may be installed on the 700/800-series MVME162LX. Install the IPs on the board as follows:

1. Each IP has two 50-pin connectors that plug into two corresponding 50-pin connectors on the MVME162LX: J5/J6, J7/J8. See Figure 2-1 for the MVME162LX connector locations.
  - Orient the IP(s) so that the tapered connector shells mate properly. Plug IP\_a into connectors J5 and J6; plug IP\_b into J7 and J8. If a double-sized IP is used, plug IP\_ab into J5, J6, J7, and J8.
2. Two additional 50-pin connectors (J3 and J4) are provided behind the MVME162LX front panel for external cabling connections to the IP modules. There is a one-to-one correspondence between the signals on the cabling connectors and the signals on the associated IP connectors (i.e., J4 has the same IP\_a signals as J5; J3 has the same IP\_b signals as J7).
  - Connect user-supplied 50-pin cables to J3 and J4 as needed. Because of the varying requirements for each different kind of IP, Motorola does not supply these cables.
  - Bring the IP cables out the narrow slot in the MVME162LX front panel and attach them to the appropriate external equipment, depending on the nature of the particular IP(s).

## MVME162LX Installation

With EPROMs and IPs installed and headers properly configured, proceed as follows to install the MVME162LX in the VME chassis:

1. Turn all equipment power OFF and disconnect the power cable from the AC power source.



### Caution

Inserting or removing modules while power is applied could result in damage to module components.



### Warning

Dangerous voltages, capable of causing death, are present in this equipment. Use extreme caution when handling, testing, and adjusting.

2. Remove the chassis cover as instructed in the user's manual for the equipment.
3. Remove the filler panel from the card slot where you are going to install the MVME162LX.
  - If you intend to use the MVME162LX as system controller, it must occupy the leftmost card slot (slot 1). The system controller must be in slot 1 to correctly initiate the bus-grant daisy-chain and to ensure proper operation of the IACK daisy-chain driver.
  - If you do not intend to use the MVME162LX as system controller, it can occupy any unused double-height card slot.
4. Slide the MVME162LX into the selected card slot. Be sure the module is seated properly in the P1 and P2 connectors on the backplane. Do not damage or bend connector pins.
5. Secure the MVME162LX in the chassis with the screws provided, making good contact with the transverse mounting rails to minimize RF emissions.

6. On the chassis backplane, remove the INTERRUPT ACKNOWLEDGE (IACK) and BUS GRANT (BG) jumpers from the header for the card slot occupied by the MVME162LX.

**Note** Some VME backplanes (e.g., those used in Motorola “Modular Chassis” systems) have an autojumping feature for automatic propagation of the IACK and BG signals. Step 6 does not apply to such backplane designs.

7. Connect the appropriate cable(s) to the MVME162LX panel connectors for the EIA-232-D serial ports, SCSI port, and LAN Ethernet port.
  - Note that some cables are not provided with the MVME162LX and must be made or purchased by the user. (Motorola recommends shielded cable for all peripheral connections to minimize radiation.)
8. Connect the peripheral(s) to the cable(s).
9. Install any other required VME modules in the system.
10. Replace the chassis cover.
11. Connect the power cable to the AC power source and turn the equipment power ON.

## System Considerations

The 700/800-series MVME162LX draws power from both the P1 and the P2 connectors on the VMEbus backplane. P2 is also used for the upper 16 bits of data in 32-bit transfers, and for the upper 8 address lines in extended addressing mode. The MVME162LX may not operate properly without its main board connected to VMEbus backplane connectors P1 and P2.

Whether the MVME162LX operates as VMEbus master or as VMEbus slave, it is configured for 32 bits of address and 32 bits of data (A32/D32). However, it handles A16 or A24 devices in the address ranges indicated in Chapter 3. D8 and/or D16 devices in the system must be handled by the MC68040 software. Refer to the memory maps in the *MVME162LX Embedded Controller Programmer's Reference Guide*.

The MVME162LX contains shared onboard DRAM whose base address is software-selectable. Both the onboard processor and offboard VMEbus devices see this local DRAM at base physical address \$00000000, as programmed by the MVME162Bug firmware. This may be changed via software to any other base address. Refer to the *MVME162LX Embedded Controller Programmer's Reference Guide* for more information.

If the MVME162LX tries to access offboard resources in a nonexistent location and is not system controller, and if the system does not have a global bus timeout, the MVME162LX waits forever for the VMEbus cycle to complete. This will cause the system to lock up. There is only one situation in which the system might lack this global bus timeout: when the MVME162LX is not the system controller and there is no global bus timeout elsewhere in the system.

Multiple MVME162LXs may be installed in a single VME chassis. In general, hardware multiprocessor features are supported.

**Note** If you are installing multiple MVME162LXs in an MVME945 chassis, do not install one in slot 12. The height of the IP modules may cause clearance difficulties in that slot position.

Other MPUs on the VMEbus can interrupt, disable, communicate with, and determine the operational status of the processor(s). One register of the GCSR (global control/status register) set includes four bits that function as location monitors to allow one MVME162LX processor to broadcast a signal to any other MVME162LX processors. All eight registers are accessible from any local processor as well as from the VMEbus.


The following circuits are protected by solid-state fuses that open during overload conditions: LAN/AUI, SCSI terminator, remote reset connector, IndustryPack 5V, and  $\pm 12V$ .

The FUSES LED illuminates to indicate that all fuses are functioning correctly. If a fuse opens, you will have to remove power for several minutes to let the fuse reset to a closed or shorted condition.

The MVME162LX uses two Zilog Z85230 serial port controllers to implement the four serial communications interfaces. Each interface supports CTS, DCD, RTS, and DTR control signals as well as the TXD and RXD transmit/receive data signals. Because the serial clocks are omitted in the MVME162LX implementation, serial communications are strictly asynchronous. The Z85230 is interfaced as DTE (data terminal equipment) with EIA-232-D signal levels. The serial ports are routed to four RJ-45 connectors on the front panel.


The figures on the following pages supply connection diagrams for the four serial ports on the MVME162LX. These ports are connected to external devices through cables connected to the front panel.

Figure 2-2 diagrams the pin assignments required in a cable to adapt a DB-25 DTE device to the RJ-45 connectors.



**Figure 2-2. DB-25 DTE-to-RJ-45 Adapter**


Figure 2-3 diagrams the pin assignments required in a cable to adapt a DB-25 DCE device to a RJ-45 connector.



**Figure 2-3. DB-25 DCE-to-RJ-45 Adapter**



Figure 2-4 diagrams the pin assignments required in a typical 8-conductor serial cable having RJ-45 connectors at both ends. Note that all wires are crossed.



**Figure 2-4. Typical RJ-45 Serial Cable**



## Overview of M68000 Firmware

The firmware for the M68000-based (68K) series of board and system level products has a common genealogy, deriving from the debugger firmware currently used on all Motorola M68000-based CPU modules. The M68000 firmware family provides a high degree of functionality and user friendliness, and yet stresses portability and ease of maintenance. The M68000 firmware implementation on the 700/800-series MVME162LX MC68040-based Embedded Controller is known as the MVME162Bug, or 162Bug. It includes diagnostics for testing and configuring IndustryPack modules.

## Description of 162Bug

The 162Bug package, MVME162Bug, is a powerful evaluation and debugging tool for systems built around the MVME162LX CISC-based microcomputers. Facilities are available for loading and executing user programs under complete operator control for system evaluation. 162Bug includes commands for display and modification of memory, breakpoint and tracing capabilities, a powerful assembler/disassembler useful for patching programs, and a power-up self test which verifies the integrity of the system. Various 162Bug routines that handle I/O, data conversion, and string functions are available to user programs through the TRAP #15 system calls.

162Bug consists of three parts:

- ❑ A command-driven user-interactive software debugger, described in Chapter 4 and hereinafter referred to as “the debugger” or “162Bug”.

- ❑ A command-driven diagnostic package for the MVME162LX hardware, described in the *MVME162Bug Diagnostics Manual* and hereinafter referred to as “the diagnostics”.
- ❑ A user interface that accepts commands from the system console terminal.

When using 162Bug, you operate out of either the debugger directory or the diagnostic directory. If you are in the debugger directory, the debugger prompt

```
162-Bug>
```

is displayed and you have all of the debugger commands at your disposal. If you are in the diagnostic directory, the diagnostic prompt

```
162-Diag>
```

is displayed and you have all of the diagnostic commands at your disposal as well as all of the debugger commands. You may switch between directories by using the Switch Directories (**SD**) command, or you may examine the commands in your current directory by using the Help (**HE**) command.

Because 162Bug is command-driven, it performs its various operations in response to user commands entered at the keyboard. When you enter a command, 162Bug executes the command and the prompt reappears. However, if you enter a command that causes execution of user target code (for example, **GO**), then control may or may not return to 162Bug, depending on the outcome of the user program.

If you have used one or more of Motorola's other debugging packages, you will find the CISC 162Bug very similar. Some effort has also been made to make the interactive commands more consistent. For example, delimiters between commands and arguments may now be commas or spaces interchangeably.

# 162Bug Implementation

MVME162Bug is written largely in the “C” programming language, providing benefits of portability and maintainability. Where necessary, assembler has been used in the form of separately compiled modules containing only assembler code — no mixed language modules are used.

Physically, 162Bug is contained in a single 27C040 DIP EPROM installed in socket XU2, providing 512KB (128K longwords) of storage. As an option, the 162Bug firmware can be loaded and executed in a single Flash memory chip. The executable code is checksummed at every power-on or reset firmware entry, and the result (which includes a pre-calculated checksum contained in the memory devices), is tested for an expected zero. Thus, users are cautioned against modification of the memory devices unless re-checksum precautions are taken.

## Installation and Startup

Follow the steps below to operate 162Bug with the MVME162LX module. 162Bug is factory-installed in EPROM, except in the no-VMEbus case.



### Caution

Inserting or removing boards while power is applied could damage board components.

1. Turn all equipment power OFF. Refer to the *Hardware Preparation* section in Chapter 2 and install/remove jumpers on headers as required for your particular application.

Jumpers on header J21 affect 162Bug operation as described below. The default condition for the MVME162LX is with seven jumpers installed, between pins 1-2, 3-4, 5-6, 9-10, 11-12, 13-14, and 15-16 (no jumper between pins 7-8).

Models with no VMEbus interface have a jumper between pins 7-8 as well.

These readable jumpers are read as a register (at \$FFF4202D) on the Memory Controller (MC2chip) ASIC. The bit values are read as a zero when the jumper is installed, and as a one when the jumper is removed. This jumper block (header J21) contains eight bits. Refer also to the *MVME162LX Embedded Controller Programmer's Reference Guide* for more information on the MC2chip.

The MVME162Bug reserves/defines the four lower order bits (GPI3 to GPI0). The following is the description for the bits reserved/defined by the debugger:

Bit	J21 Pins	Description
Bit #0 (GPI0)	1-2	When set to 1 (high), instructs the debugger to use local Static RAM for its work page (i.e., variables, stack, vector tables, etc.).
Bit #1 (GPI1)	3-4	When set to 1 (high), instructs the debugger to use the default setup/operation parameters in Flash or ROM versus the user setup/operation parameters in Non-Volatile RAM (NVRAM). This is the same as depressing the RESET and ABORT switches at the same time. This feature can be used in the event the user setup is corrupted or does not meet a sanity check. Refer to the ENV command (Appendix A) for the Flash/ROM defaults.
Bit #2 (GPI2)	5-6	Reserved for future use.
Bit #3 (GPI3)	7-8	When this bit is a zero (low), it informs the debugger that it is executing out of the Flash memories. When this bit is a one (high), it informs the debugger that it is executing out of the PROM.
Bit #4 (GPI4)	9-10	Open to your application.
Bit #5 (GPI5)	11-12	Open to your application.
Bit #6 (GPI6)	13-14	Open to your application.
Bit #7 (GPI7)	15-16	Open to your application.

Note that when the MVME162LX comes up in a cold reset, 162Bug runs in Board Mode. Using the Environment (ENV) or MENU commands can make 162Bug run in System Mode. Refer to Appendix A for details.

2. Configure header J1 by installing/removing a jumper between pins 1 and 2. A jumper installed/removed enables/disables the system controller function of the MVME162LX.
3. The jumper on header J11 configures the IP bus clock for either 8MHz or 32MHz. The factory configuration puts a jumper between J11 pins 1 and 2 for an 8MHz clock. Verify that this setting is appropriate for your application.
4. The jumper on header J18 enables/disables the IP bus strobe function on the MVME162LX. The factory configuration puts a jumper between J18 pins 1 and 2 to connect the Strobe\* signal to the IP2 chip. Verify that the strobe line should be connected in your application.
5. The jumpers on header J19 enable/disable the IP DMA snoop function on the MVME162LX. The factory configuration has J19 fully jumpered to inhibit the snoop function. Verify that snooping should be disabled in your IP DMA application.
6. Refer to the setup procedure for your particular chassis or system for details concerning the installation of the MVME162LX.
7. Connect the terminal that is to be used as the 162Bug system console to the default debug EIA-232-D port at serial port 1 on the front panel of the MVME162LX. Refer to Chapter 2 for other connection options. Set up the terminal as follows:
  - eight bits per character
  - one stop bit per character
  - parity disabled (no parity)
  - baud rate 9600 baud (default baud rate of MVME162LX ports at powerup)

After power-up, you can reconfigure the baud rate of the debug port if necessary by using the 162Bug firmware's Port Format (**PF**) command.

- Note** In order for high-baud rate serial communication between 162Bug and the terminal to work, the terminal must do some form of handshaking. If the terminal being used does not do hardware handshaking via the CTS line, then it must do XON/XOFF handshaking. If you get garbled messages and missing characters, then you should check the terminal to make sure XON/XOFF handshaking is enabled.
8. If you want to connect devices (such as a host computer system and/or a serial printer) to the other EIA-232-D port connectors, connect the appropriate cables and configure the port(s) as detailed in step 4 above. After power-up, you can reconfigure this (these) port(s) by programming the MVME162LX Z85230 Serial Communications Controllers (SCCs), or by using the 162Bug **PF** command.
  9. EPROM/Flash configuration header J20 should be set to configuration 2, with jumpers between J20 pins 5 and 6, 8 and 10, and 9 and 11. This sets it up for 512K x 8 EPROMs.
  10. Power up the system. 162Bug executes some self-checks and displays the debugger prompt

```
162-Bug>
```

(if 162Bug is in Board Mode). However, if the **ENV** command (Appendix A) has put 162Bug in System Mode, the system performs a selftest and tries to autoboot. Refer to the **ENV** and **MENU** commands (Table 4-3).

If the confidence test fails, the test is aborted when the first fault is encountered. If possible, an appropriate message is displayed, and control then returns to the menu.



11. Before using the MVME162LX after the initial installation, set the date and time using the following command line structure:

```
162-Bug> SET [mmdyyhhmm] | [+ / -CAL>;C]
```

For example, the following command line starts the real-time clock and sets the date and time to 10:37 a.m., November 7, 1997:

```
162-Bug> SET 1107971037
```

The board's self-tests and operating systems require that the real-time clock be running.

## Prom Versions

When you are using a PROM version of the 162Bug (e.g., in the case of the 700/800-series MVME162LX) and you wish to execute the debugger out of Flash memory rather than from PROM in subsequent sessions, proceed as follows after the board is up and running:

1. Install a jumper across J16 pins 1-2 to enable Flash writes.
2. Copy the PROM contents to Flash memory with the **PFLASH** command as follows:

```
162-Bug> PFLASH FF800000:80000 FFA00000
```

3. Remove the jumper from J16 pins 1-2 to disable subsequent Flash writes.
4. Install a jumper at J21 pins 7 and 8. (162Bug always executes from memory location FF800000; the state of J21 determines whether that location is in PROM or Flash.)

## Autoboot

Autoboot is a software routine that is contained in the 162Bug Flash/PROM to provide an independent mechanism for booting an operating system. This autoboot routine automatically scans for

controllers and devices in a specified sequence until a valid bootable device containing a boot media is found or the list is exhausted. If a valid bootable device is found, a boot from that device is started. The controller scanning sequence goes from the lowest controller Logical Unit Number (LUN) detected to the highest LUN detected. Controllers, devices, and their LUNs are listed in Appendix B.

At powerup, Autoboot is enabled, and providing the drive and controller numbers encountered are valid, the following message is displayed upon the system console:

```
Autoboot in progress... To abort hit <BREAK>
```

Following this message there is a delay to allow you an opportunity to abort the Autoboot process if you wish. Then the actual I/O is begun: the program pointed to within the volume ID of the media specified is loaded into RAM and control passed to it. If, however, during this time you want to gain control without Autoboot, you can press the <BREAK> key or the software ABORT or RESET switches.

Autoboot is controlled by parameters contained in the **ENV** command. These parameters allow the selection of specific boot devices and files, and allow programming of the Boot delay. Refer to the **ENV** command in Appendix A for more details.

**Caution**

Although streaming tape can be used to autoboot, the same power supply must be connected to the streaming tape drive, the controller, and the MVME162LX. At powerup, the tape controller will position the streaming tape to load point where the volume ID can correctly be read and used.

If, however, the MVME162LX loses power but the controller does not, and the tape happens to be at load point, the sequences of commands required (attach and rewind) cannot be given to the controller and autoboot will not be successful.

## ROMboot

As shipped from the factory, 162Bug occupies an EPROM installed in socket XU2. This leaves one socket (XU1) and the Flash memory available for your use. Contact your Motorola sales office for assistance. This function is configured/enabled by the Environment (**ENV**) command (refer to Appendix A) and executed at powerup (optionally also at reset) or by the **RB** command assuming there is valid code in the memory devices (or optionally elsewhere on the board or VMEbus) to support it. If ROMboot code is installed, a user-written routine is given control (if the routine meets the format requirements). One use of ROMboot might be resetting SYSFAIL\* on an unintelligent controller module. The **NORB** command disables the function.

For a user's ROMboot module to gain control through the ROMboot linkage, four requirements must be met:

- ❑ Power must have just been applied (but the **ENV** command can change this to also respond to any reset).
- ❑ Your routine must be located within the MVME162LX Flash/PROM memory map (but the **ENV** command can change this to any other portion of the onboard memory, or even offboard VMEbus memory).
- ❑ The ASCII string "BOOT" must be located within the specified memory range.
- ❑ Your routine must pass a checksum test, which ensures that this routine was really intended to receive control at powerup.

For complete details on how to use ROMboot, refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual*.

## Network Boot

Network Auto Boot is a software routine contained in the 162Bug Flash/PROM that provides a mechanism for booting an operating system using a network (local Ethernet interface) as the boot device. If enabled (via **ENV** — refer to Appendix A), the Network Auto Boot routine automatically scans for controllers and devices in a specified sequence until a valid bootable device containing a boot media is found or the list is exhausted. If a valid bootable device is found, a boot from that device is started. The controller scanning sequence goes from the lowest controller Logical Unit Number (LUN) detected to the highest LUN detected. (Refer to Appendix C for default LUNs.)

At powerup, if Network Boot is enabled and the controller and device LUNs are valid, the following message is displayed at the system console:

```
Network Boot in progress... To abort hit <BREAK>
```

Following this message there is a delay to let you abort the autoboot process if you wish. Then the actual I/O is begun: the program pointed to within the volume ID of the media specified is loaded into RAM and control passed to it. If, however, during this time you want to gain control without Network Boot, you can press the <BREAK> key or the software ABORT or RESET switches.

Network Auto Boot is controlled by parameters contained in the **NIOT** and **ENV** commands. These parameters allow the selection of specific boot devices, systems, and files, and allow programming of the Boot delay. Refer to the **ENV** command in Appendix A for more details.

## Restarting the System

You can initialize the system to a known state in three different ways: reset, abort, and break. Each has characteristics which make it more appropriate than the others in certain situations.

The debugger has a special feature available for reset conditions. You activate it by pressing the RESET and ABORT switches at the same time, releasing RESET first, then releasing ABORT seven seconds later.

This “double-button reset” feature instructs the debugger to use the default setup/operation parameters in ROM versus your setup/operation parameters in NVRAM. You can use this feature in the event your setup/operation parameters are corrupted or do not meet a sanity check. Refer to the ENV command (Appendix A) for the ROM defaults.

## Reset

Pressing and releasing the MVME162LX front panel RESET switch initiates a system reset. COLD and WARM reset modes are available. By default, 162Bug is in COLD mode. During COLD resets, a total system initialization takes place, as if the MVME162LX had just been powered up. All static variables (including disk device and controller parameters) are restored to their default states. The breakpoint table and offset registers are cleared. The target registers are invalidated. Input and output character queues are cleared. Onboard devices (timer, serial ports, etc.) are reset, and the two serial ports are reconfigured to their default state.

During WARM resets, the 162Bug variables and tables are preserved, as well as the target state registers and breakpoints.

Reset must be used if the processor ever halts, or if the 162Bug environment is ever lost (vector table is destroyed, stack corrupted, etc.).

## Abort

The Abort function is invoked by pressing and releasing the ABORT switch on the MVME162LX front panel. Whenever abort is invoked when executing a user program (running target code), a snapshot of the processor state is captured and stored in the target registers.

For this reason, abort is most appropriate when terminating a user program that is being debugged. Abort should be used to regain control if the program gets caught in a loop, etc. The target PC, register contents, etc., help to pinpoint the malfunction.

Pressing and releasing the ABORT switch generates a local board condition which may interrupt the processor if enabled. The target registers, reflecting the machine state at the time the ABORT switch was pressed, are displayed on the screen. Any breakpoints installed in your code are removed and the breakpoint table remains intact. Control is returned to the debugger.

## Break

A “power-break” is generated by pressing and releasing the <BREAK> key on the terminal keyboard. Break does not generate an interrupt. The only time break is recognized is when characters are sent or received by the console port. Break removes any breakpoints in your code and keeps the breakpoint table intact. Break also takes a snapshot of the machine state if the function was entered using SYSCALL. This machine state is then accessible to you for diagnostic purposes.

Many times it may be desirable to terminate a debugger command before its completion — during the display of a large block of memory, for example. Break allows you to terminate the command.

## SYSFAIL\* Assertion/Negation

Upon entering a reset/powerup condition, the debugger asserts the VMEbus SYSFAIL\* line (refer to the VMEbus specification). SYSFAIL\* stays asserted if any of the following has occurred:

- Confidence test failure
- NVRAM checksum error
- NVRAM low battery condition
- Local memory configuration status

- ❑ self test (if system mode) has completed with error
- ❑ MPU clock speed calculation failure

After debugger initialization is done and none of the above situations have occurred, the SYSFAIL\* line is negated. This indicates to the user or VMEbus masters the state of the debugger. In a multi-computer configuration, other VMEbus masters could view the pertinent control and status registers to determine which CPU is asserting SYSFAIL\*. SYSFAIL\* assertion/negation is also affected by the ENV command. Refer to Appendix A.

## MPU Clock Speed Calculation

The clock speed of the microprocessor is calculated and checked against a user definable parameter housed in NVRAM (refer to the CNFG command description in Appendix A). If the check fails, a warning message is displayed. The calculated clock speed is also checked against known clock speeds and tolerances.

## Memory Requirements

The program portion of 162Bug is approximately 512KB of code, consisting of download, debugger, and diagnostic packages and contained entirely in Flash or PROM.

The 162Bug executes from \$FF800000 whether in Flash or PROM. If you remove the jumper at J21 pins 7 and 8, the address spaces of the Flash and PROM are swapped. For 700/800-series MVME162LX boards, the factory shipping configuration is with jumper J21 pins 7-8 removed (so that 162Bug operates out of EPROM).

The 162Bug initial stack completely changes 8KB of SRAM memory at addresses offset \$C000 from the SRAM base address, at power-up or reset.

Type of Memory Present	Default DRAM Base Address	Default SRAM Base Address
A single DRAM mezzanine	\$00000000	\$FFE00000 (onboard SRAM)
A single SRAM mezzanine	N/A	\$00000000
A DRAM mezzanine stacked with an SRAM mezzanine	\$00000000	\$E1000000
Two DRAM mezzanines stacked	\$00000000	\$FFE00000 (onboard SRAM)

DRAM can be ECC or parity type. DRAM mezzanines are mapped in contiguously starting at zero (\$00000000), largest first. With two mezzanines of the same size but different type, parity DRAM is mapped to the selected base address and the ECC mezzanine will follow. If both are ECC type, the bottom one is first.

The 162Bug requires 2KB of NVRAM for storage of board configuration, communication, and booting parameters. This storage area begins at \$FFFC16F8 and ends at \$FFFC1EF7 (for details, refer to the maps in the *MVME162LX Embedded Controller Programmer's Reference Guide*).

162Bug requires a minimum of 64KB of contiguous read/write memory to operate. The ENV command controls where this block of memory is located. Regardless of where the onboard RAM is located, the first 64KB is used for 162Bug stack and static variable space and the rest is reserved as user space. Whenever the MVME162LX is reset, the target PC is initialized to the address corresponding to the beginning of the user space, and the target stack pointers are initialized to addresses within the user space, with the target Interrupt Stack Pointer (ISP) set to the top of the user space.



## Disk I/O Support

162Bug can initiate disk input/output by communicating with intelligent disk controller modules over the VMEbus. Disk support facilities built into 162Bug consist of command-level disk operations, disk I/O system calls (only via one of the TRAP #15 instructions) for use by user programs, and defined data structures for disk parameters.

Parameters such as the address where the module is mapped and the type and number of devices attached to the controller module are kept in tables by 162Bug. Default values for these parameters are assigned at powerup and cold-start reset, but may be altered as described in the section on default parameters, later in this chapter.

Appendix B contains a list of the controllers presently supported, as well as a list of the default configurations for each controller.

## Blocks Versus Sectors

The logical block defines the unit of information for disk devices. A disk is viewed by 162Bug as a storage area divided into logical blocks. By default, the logical block size is set to 256 bytes for every block device in the system. The block size can be changed on a per device basis with the **IOT** command.

The sector defines the unit of information for the media itself, as viewed by the controller. The sector size varies for different controllers, and the value for a specific device can be displayed and changed with the **IOT** command.

When a disk transfer is requested, the start and size of the transfer is specified in blocks. 162Bug translates this into an equivalent sector specification, which is then passed on to the controller to initiate the transfer. If the conversion from blocks to sectors yields a fractional sector count, an error is returned and no data is transferred.

## Device Probe Function

A device probe with entry into the device descriptor table is done whenever a specified device is accessed; i.e., when system calls `.DSKRD`, `.DSKWR`, `.DSKCFIG`, `.DSKFMT`, and `.DSKCTRL`, and debugger commands **BH**, **BO**, **IOC**, **IOP**, **IOT**, **MAR**, and **MAW** are used.

The device probe mechanism utilizes the SCSI commands Inquiry and Mode Sense. If the specified controller is non-SCSI, the probe simply returns a status of “device present and unknown”. The device probe makes an entry into the device descriptor table with the pertinent data. After an entry has been made, the next time a probe is done it simply returns with “device present” status (pointer to the device descriptor).

## Disk I/O via 162Bug Commands

These following 162Bug commands are provided for disk I/O. Detailed instructions for their use are found in the *Debugging Package for Motorola 68K CISC CPUs User's Manual*. When a command is issued to a particular controller LUN and device LUN, these LUNs are remembered by 162Bug so that the next disk command defaults to use the same controller and device.

### IOI (Input/Output Inquiry)

This command is used to probe the system for all possible CLUN/DLUN combinations and display inquiry data for devices which support it. The device descriptor table only has space for 16 device descriptors; with the **IOI** command, you can view the table and clear it if necessary.

### IOP (Physical I/O to Disk)

**IOP** allows you to read or write blocks of data, or to format the specified device in a certain way. **IOP** creates a command packet from the arguments you have specified, and then invokes the proper system call function to carry out the operation.

**IOT (I/O Teach)**

**IOT** allows you to change any configurable parameters and attributes of the device. In addition, it allows you to see the controllers available in the system.

**IOC (I/O Control)**

**IOC** allows you to send command packets as defined by the particular controller directly. **IOC** can also be used to look at the resultant device packet after using the **IOP** command.

**BO (Bootstrap Operating System)**

**BO** reads an operating system or control program from the specified device into memory, and then transfers control to it.

**BH (Bootstrap and Halt)**

**BH** reads an operating system or control program from a specified device into memory, and then returns control to 162Bug. It is used as a debugging tool.

**Disk I/O via 162Bug System Calls**

All operations that actually access the disk are done directly or indirectly by 162Bug TRAP #15 system calls. (The command-level disk operations provide a convenient way of using these system calls without writing and executing a program.)

The following system calls are provided to allow user programs to do disk I/O:

.DSKRD	Disk read. System call to read blocks from a disk into memory.
.DSKWR	Disk write. System call to write blocks from memory onto a disk.
.DSKCFIG	Disk configure. This function allows you to change the configuration of the specified device.
.DSKFMT	Disk format. This function allows you to send a format command to the specified device.
.DSKCTRL	Disk control. This function is used to implement any special device control functions that cannot be accommodated easily with any of the other disk functions.

Refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for information on using these and other system calls.

To perform a disk operation, 162Bug must eventually present a particular disk controller module with a controller command packet which has been especially prepared for that type of controller module. (This is accomplished in the respective controller driver module.) A command packet for one type of controller module usually does not have the same format as a command packet for a different type of module. The system call facilities which do disk I/O accept a generalized (controller-independent) packet format as an argument, and translate it into a controller-specific packet, which is then sent to the specified device. Refer to the system call descriptions in the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for details on the format and construction of these standardized user packets.

The packets which a controller module expects to be given vary from controller to controller. The disk driver module for the particular hardware module (board) must take the standardized packet given to a trap function and create a new packet which is

specifically tailored for the disk drive controller it is sent to. Refer to documentation on the particular controller module for the format of its packets, and for using the **IOC** command.

## Default 162Bug Controller and Device Parameters

162Bug initializes the parameter tables for a default configuration of controllers and devices (refer to Appendix B). If the system needs to be configured differently than this default configuration (for example, to use a 70MB Winchester drive where the default is a 40MB Winchester drive), then these tables must be changed.

There are two ways to change the parameter tables:

- ❑ Using **BO** or **BH**. When you invoke one of these commands, the configuration area of the disk is read and the parameters corresponding to that device are rewritten according to the parameter information contained in the configuration area. This is a temporary change. If a cold-start reset occurs, then the default parameter information is written back into the tables.
- ❑ Using the **IOT**. You can use this command to reconfigure the parameter table manually for any controller and/or device that is different from the default. This is also a temporary change and is overwritten if a cold-start reset occurs.

## Disk I/O Error Codes

162Bug returns an error code if an attempted disk operation is unsuccessful.

## Network I/O Support

The Network Boot Firmware provides the capability to boot the CPU through the Flash/PROM debugger using a network (local Ethernet interface) as the boot device.

The booting process is executed in two distinct phases.

- The first phase allows the diskless remote node to discover its network identify and the name of the file to be booted.
- The second phase has the diskless remote node reading the boot file across the network into its memory.

The various modules (capabilities) and the dependencies of these modules that support the overall network boot function are described in the following paragraphs.

## **Intel 82596 LAN Coprocessor Ethernet Driver**

This driver manages/surrounds the Intel 82596 LAN Coprocessor. Management is in the scope of the reception of packets, the transmission of packets, receive buffer flushing, and interface initialization.

This module ensures that the packaging and unpackaging of Ethernet packets is done correctly in the Boot PROM.

## **UDP/IP Protocol Modules**

The Internet Protocol (IP) is designed for use in interconnected systems of packet-switched computer communication networks. The Internet protocol provides for transmitting of blocks of data called datagrams (hence User Datagram Protocol, or UDP) from sources to destinations, where sources and destinations are hosts identified by fixed length addresses.

The UDP/IP protocols are necessary for the TFTP and BOOTP protocols; TFTP and BOOTP require a UDP/IP connection.

## RARP/ARP Protocol Modules

The Reverse Address Resolution Protocol (RARP) basically consists of an identity-less node broadcasting a “whoami” packet onto the Ethernet, and waiting for an answer. The RARP server fills an Ethernet reply packet up with the target's Internet Address and sends it.

The Address Resolution Protocol (ARP) basically provides a method of converting protocol addresses (e.g., IP addresses) to local area network addresses (e.g., Ethernet addresses). The RARP protocol module supports systems which do not support the BOOTP protocol (next paragraph).

## BOOTP Protocol Module

The Bootstrap Protocol (BOOTP) basically allows a diskless client machine to discover its own IP address, the address of a server host, and the name of a file to be loaded into memory and executed.

## TFTP Protocol Module

The Trivial File Transfer Protocol (TFTP) is a simple protocol to transfer files. It is implemented on top of the Internet User Datagram Protocol (UDP or Datagram) so it may be used to move files between machines on different networks implementing UDP. The only thing it can do is read and write files from/to a remote server.

## Network Boot Control Module

The control capability of the Network Boot Control Module is needed to tie together all the necessary modules (capabilities) and to sequence the booting process. The booting sequence consists of two phases: the first phase is labeled “address determination and bootfile selection” and the second phase is labeled “file transfer”. The first phase will utilize the RARP/BOOTP capability and the second phase will utilize the TFTP capability.

## Network I/O Error Codes

162Bug returns an error code if an attempted network operation is unsuccessful.

## Multiprocessor Support

The MVME162LX dual-port RAM feature makes the shared RAM available to remote processors as well as to the local processor. This can be done by either of the following two methods. Either method can be enabled/disabled by the **ENV** command as its Remote Start Switch Method (refer to Appendix A).

### Multiprocessor Control Register (MPCR) Method

A remote processor can initiate program execution in the local MVME162LX dual-port RAM by issuing a remote **GO** command using the Multiprocessor Control Register (MPCR). The MPCR, located at shared RAM location of \$800 offset from the base address the debugger loads it at, contains one of two longwords used to control communication between processors. The MPCR contents are organized as follows:

\$800 

*	N/A	N/A	N/A
---	-----	-----	-----

 (MPCR)

The status codes stored in the MPCR are of two types:

- ❑ Status returned (from the monitor)
- ❑ Status set (by the bus master)

The status codes that may be returned from the monitor are:

- ASCII 0 (HEX 00) - Wait. Initialization not yet complete.
- ASCII E (HEX 45) - Code pointed to by the MPAR address is executing.
- ASCII P (HEX 50) - Program Flash Memory. The MPAR is set to the address of the Flash memory program control packet.
- ASCII R (HEX 52) - Ready. The firmware monitor is watching for a change.



You can only program Flash memory by the MPCR method. Refer to the .PFLASH system call in the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for a description of the Flash memory program control packet structure.

The status codes that may be set by the bus master are:

- ASCII G (HEX 47) - Use Go Direct (GD) logic specifying the MPAR address.
- ASCII B (HEX 42) - Install breakpoints using the Go (G) logic.

The Multiprocessor Address Register (MPAR), located in shared RAM location of \$804 offset from the base address the debugger loads it at, contains the second of two longwords used to control communication between processors. The MPAR contents specify the address at which execution for the remote processor is to begin if the MPCR contains a G or B. The MPAR is organized as follows:

\$804 

*	*	*	*
---	---	---	---

 (MPAR)

At power-up, the debug monitor's self-test routines initialize RAM, including the memory locations used for multi-processor support (\$800 through \$807).

The MPCR contains \$00 at powerup, indicating that initialization is not yet complete. As the initialization proceeds, the execution path comes to the "prompt" routine. Before sending the prompt, this routine places an R in the MPCR to indicate that initialization is complete. Then the prompt is sent.

If no terminal is connected to the port, the MPCR is still polled to see whether an external processor requires control to be passed to the dual-port RAM. If a terminal does respond, the MPCR is polled for the same purpose while the serial port is being polled for user input.

An ASCII G placed in the MPCR by a remote processor indicates that the Go Direct type of transfer is requested. An ASCII B in the MPCR indicates that breakpoints are to be armed before control is transferred (as with the GO command).

In either sequence, an E is placed in the MPCR to indicate that execution is underway just before control is passed to RAM. (Any remote processor could examine the MPCR contents.)

If the code being executed in dual-port RAM is to reenter the debug monitor, a TRAP #15 call using function \$0063 (SYSCALL .RETURN) returns control to the monitor with a new display prompt. Note that every time the debug monitor returns to the prompt, an R is moved into the MPCR to indicate that control can be transferred once again to a specified RAM location.

## GCSR Method

A remote processor can initiate program execution in the local MVME162LX dual-port RAM by issuing a remote **GO** command using the VMEchip2 Global Control and Status Registers (GCSR). The remote processor places the MVME162LX execution address in general purpose registers 0 and 1 (GPCSR0 and GPCSR1). The remote processor then sets bit 8 (SIG0) of the VMEchip2 LM/SIG register. This causes the MVME162LX to install breakpoints and begin execution. The result is identical to the MPCR method (with status code B) described in the previous section.

The GCSR registers are accessed in the VMEbus short I/O space. Each general purpose register is two bytes wide, occurring at an even address. The general purpose register number 0 is at an offset of \$8 (local bus) or \$4 (VMEbus) from the start of the GCSR registers. The local bus base address for the GCSR is \$FFF40100. The VMEbus base address for the GCSR depends on the group select value and the board select value programmed in the Local Control and Status Registers (LCSR) of the MVME162LX. The execution address is formed by reading the GCSR general purpose registers in the following manner:

GPCSR0	used as the upper 16 bits of the address
GPCSR1	used as the lower 16 bits of the address

The address appears as:

GPCSR0	GPCSR1
--------	--------

## Diagnostic Facilities

The 162Bug package includes a set of hardware diagnostics for testing and troubleshooting the MVME162LX. To use the diagnostics, switch directories to the diagnostic directory. If you are in the debugger directory, you can switch to the diagnostic directory with the debugger command `Switch Directories (SD)`. The diagnostic prompt

```
162-Diag>
```

appears. Refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for complete descriptions of the diagnostic routines available and instructions on how to invoke them. Note that some diagnostics depend on restart defaults that are set up only in a particular restart mode. The documentation for such diagnostics includes restart information.

## Manufacturing Test Process

During the manufacturing process for MVME162LXs, the manufacturing test parameters and testing state flags are stored in NVRAM. These strings are installed during the manufacturing process and result in the product performing manufacturing tests. None of these tests harm the product or system into which a board is installed. Entering an ASCII break on the console port from a terminal terminates these tests.

The two state flags that start the test processes are:

```
FLASH EMPTY$00122984
```

and

```
Burnin test$00000000
```

If either string is in the first location of NVRAM (\$FFFC0000), the test process starts.

## In This Chapter

This chapter covers the following subjects:

- ❑ Entering debugger command lines
- ❑ Entering and debugging programs
- ❑ Calling system utilities from user programs
- ❑ Preserving the debugger operating environment
- ❑ Floating point support
- ❑ The 162Bug debugger command set

## Entering Debugger Command Lines

162Bug is command-driven and performs its various operations in response to user commands entered at the keyboard. When the debugger prompt

```
162-Bug>
```

appears on the terminal screen, then the debugger is ready to accept commands.

## Terminal Input/Output Control

As the command line is entered, it is stored in an internal buffer. Execution begins only after the carriage return is entered, so that you can correct entry errors, if necessary, using the control characters described below.

**Note** The presence of the upward caret ( ^ ) before a character indicates that the Control (CTRL) key must be held down while striking the character key.

^X	(cancel line)	The cursor is backspaced to the beginning of the line.
^H	(backspace)	The cursor is moved back one position.
Delete key	(delete)	Performs the same function as ^H.
^D	(redisplay)	The entire command line as entered so far is redisplayed on the following line.
^A	(repeat)	Repeats the previous line. This happens only at the command line. The last line entered is redisplayed but not executed. The cursor is positioned at the end of the line. You may enter the line as is or you can add more characters to it. You can edit the line by backspacing and typing over old characters.

When observing output from any 162Bug command, the XON and XOFF characters which are in effect for the terminal port may be entered to control the output, if the XON/XOFF protocol is enabled (default). These characters are initialized to ^S and ^Q respectively by 162Bug, but you may change them with the PF command. In the initialized (default) mode, operation is as follows:

^S	(wait)	Console output is halted.
^Q	(resume)	Console output is resumed.

When a command is entered, the debugger executes the command and the prompt reappears. However, if the command entered causes execution of user target code, for example GO, then control may or may not return to the debugger, depending on what the user program does.

For example, if a breakpoint has been specified, then control returns to the debugger when the breakpoint is encountered during execution of the user program. Alternately, the user program could return to the debugger by means of the TRAP #15 “.RETURN” function.

## Debugger Command Syntax

In general, a debugger command is made up of the following parts:

- ❑ The command identifier (i.e., **MD** or **md** for the Memory Display command). Note that either upper- or lowercase characters are allowed.
- ❑ A port number if the command is set up to work with more than one port.
- ❑ At least one intervening space before the first argument.
- ❑ Any required arguments, as specified by the command.
- ❑ An option field, set off by a semicolon (;) to specify conditions other than the default conditions of the command.

The commands are shown using a modified Backus-Naur form syntax. The metasympols used are:

## Syntactic Variables

The following syntactic variables are encountered in the command descriptions which follow. In addition, other syntactic variables may be used and are defined in the particular command description in which they occur.

<i>exp</i>	Expression (described in detail in a following section).
<i>addr</i>	Address (described in detail in a following section).
<i>count</i>	Count; the syntax is the same as for <i>exp</i> .
<i>range</i>	A range of memory addresses which may be specified either by <i>addr addr</i> or by <i>addr: count</i> .
<i>text</i>	An ASCII string of up to 255 characters, delimited at each end by the single quote mark (').

## Expression as a Parameter

An expression can be one or more numeric values separated by one of the arithmetic operators: plus (+), minus (-), multiplied by (\*), divided by (/), logical AND (&), shift left (<<), or shift right (>>).

Numeric values may be expressed in either hexadecimal, decimal, octal, or binary notation by immediately preceding them with the proper base identifier.

Base	Identifier	Examples
Hexadecimal	\$	\$FFFFFFFF
Decimal	&	&1974, &10-&4
Octal	@	@456
Binary	%	%1000110

If no base identifier is specified, then the numeric value is assumed to be hexadecimal.

A numeric value may also be expressed as a string literal of up to four characters. The string literal must begin and end with the single quote mark ('). The numeric value is interpreted as the concatenation of the ASCII values of the characters. This value is right-justified, as any other numeric value would be.

String Literal	Numeric Value (In Hexadecimal)
'A'	41
'ABC'	414243
'TEST'	54455354

Evaluation of an expression is always from left to right unless parentheses are used to group part of the expression. There is no operator precedence. Subexpressions within parentheses are evaluated first. Nested parenthetical subexpressions are evaluated from the inside out.



Valid expression examples:

Expression	Result (In Hex)	Notes
FF0011	FF0011	
45+99	DE	
&45+&99	90	
@35+@67+@10	5C	
%10011110+%1001	A7	
88<<4	880	shift left
AA&F0	A0	logical AND

The total value of the expression must be between 0 and \$FFFFFFFF.

### Address as a Parameter

Many commands use *addr* as a parameter. The syntax accepted by 162Bug is similar to the one accepted by the MC68040 one-line assembler. All control addressing modes are allowed. An “address + offset register” mode is also provided.

## Address Formats

Table 4-1 summarizes the address formats that are acceptable for address parameters in debugger command lines.

**Table 4-1. Debugger Address Parameter Formats**

Format	Example	Description
$N$	140	Absolute address+contents of automatic offset register.
$N+Rn$	130+R5	Absolute address+contents of the specified offset register (not an assembler-accepted syntax).
$(An)$	(A1)	Address register indirect. (Also post-increment, pre-decrement)
$(d,An)$ or $d(An)$	(120,A1) 120(A1)	Address register indirect with displacement (two formats accepted).
$(d,An,Xn)$ or $d(An,Xn)$	(&120,A1,D2) &120(A1,D2)	Address register indirect with index and displacement (two formats accepted).
$([bd,An,Xn],od)$	([C,A2,A3],&100)	Memory indirect preindexed.
$([bd,An],Xn,od)$	([12,A3],D2,&10)	Memory indirect postindexed.
For the memory indirect modes, fields can be omitted. For example, three of many permutations are as follows:		
$([,An],od)$	([,A1],4)	
$([bd])$	([FC1E])	
$([bd,,Xn])$	([8,,D2])	

### Notes

- $N$  — Absolute address (any valid expression).
- $An$  — Address register  $n$ .
- $Xn$  — Index register  $n$  ( $An$  or  $Dn$ ).
- $d$  — Displacement (any valid expression).
- $bd$  — Base displacement (any valid expression).
- $od$  — Outer displacement (any valid expression).
- $n$  — Register number (0 to 7).
- $Rn$  — Offset register  $n$ .

**Note** In commands with *range* specified as *addr addr*, and with size option **W** or **L** chosen, data at the second (ending) address is acted on only if the second address is a proper boundary for a word or longword, respectively.

## Offset Registers

Eight pseudo-registers (R0 through R7) called offset registers are used to simplify the debugging of relocatable and position-independent modules. The listing files in these types of programs usually start at an address (normally 0) that is not the one at which they are loaded, so it is harder to correlate addresses in the listing with addresses in the loaded program. The offset registers solve this problem by taking into account this difference and forcing the display of addresses in a relative address+offset format. Offset registers have adjustable ranges and may even have overlapping ranges. The range for each offset register is set by two addresses: base and top. Specifying the base and top addresses for an offset register sets its range. In the event that an address falls in two or more offset registers' ranges, the one that yields the least offset is chosen.

**Note** Relative addresses are limited to 1MB (5 digits), regardless of the range of the closest offset register.

Example: A portion of the listing file of an assembled, relocatable module is shown below:

```

1
2
3
4
5 0 00000000 48E78080      MOVESTR  MOVEM.LD0/A0,—(A7)
6 0 00000004 4280          CLR.LD0
7 0 00000006 1018          MOVE.B(A0)+,D0

```

```

8   0 00000008 5340                                SUBQ.W#1,D0
9   0 0000000A 12D8                                LOOP      MOVE.B(A0)+,(A1)+
10  0 0000000C 51C8FFFC                            MOVS     DBRA  D0,LOOP
11  0 00000010 4CDF0101                            MOVEM.L(A7)+,D0/A0
12  0 00000014 4E75                                RTS
13
14                                     END      END
***** TOTAL ERRORS  0——
***** TOTAL WARNINGS 0——

```

The above program was loaded at address \$0001327C.

The disassembled code is shown next:

```

162-Bug>MD 1327C;DI
0001327C 48E78080                                MOVEM.L  D0/A0,-(A7)
00013280 4280                                    CLR.L   D0
00013282 1018                                MOVE.B  (A0)+,D0
00013284 5340                                SUBQ.W  #1,D0
00013286 12D8                                MOVE.B  (A0)+,(A1)+
00013288 51C8FFFC                            DBF     D0,$13286
0001328C 4CDF0101                            MOVEM.L (A7)+,D0/A0
00013290 4E75                                RTS
162-Bug>

```

By using one of the offset registers, the disassembled code addresses can be made to match the listing file addresses as follows:

```

162-Bug>OF R0
R0 =00000000 00000000? 1327C. <CR>
162Bug>MD 0+R0;DI <CR>
0000+R0 48E78080                                MOVEM.L  D0/A0,-(A7)
00004+R0 4280                                    CLR.L   D0
00006+R0 1018                                MOVE.B  (A0)+,D0
00008+R0 5340                                SUBQ.W  #1,D0
0000A+R0 12D8                                MOVE.B  (A0)+,(A1)+
0000C+R0 51C8FFFC                            DBF     D0,$A+R0
00010+R0 4CDF0101                            MOVEM.L (A7)+,D0/A0
00014+R0 4E75                                RTS
162-Bug>

```

For additional information about the offset registers, refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual*.

## Port Numbers

Some 162Bug commands give you the option to choose the port to be used to input or output. Valid port numbers which may be used for these commands are as follows:

1. MVME162 EIA-232-D Debug (Terminal Port 0 or 00) (Port 1 on the MVME162LX J17 front panel connector). Sometimes known as the “console port”, it is used for interactive user input/output by default.
2. MVME162 EIA-232-D (Terminal Port 1 or 01) (Port 2 on the MVME162LX J17 front panel connector). Sometimes known as the “host port”, this is the default for downloading, uploading, concurrent mode, and transparent modes.
3. MVME162 EIA-232-D (Terminal Ports 2 or 02 and 3 or 03) (Port 3 and Port 4 on the MVME162LX J17 front panel connector). Additional serial ports available.

**Note** These logical port numbers (0, 1, 2, and 3) are shown in the pinouts of the MVME162LX module as SERIAL PORT 1, SERIAL PORT 2, SERIAL PORT 3, and SERIAL PORT 4, respectively. Physically, they are all part of the front panel 8-pin RJ-45 connectors on J17.

## Entering and Debugging Programs

There are various ways to enter a user program into system memory for execution:

- ❑ Create the program with the assembler/disassembler
- ❑ Download an S-record object file
- ❑ Read the program from disk

## Creating a Program with the Assembler/Disassembler

You can create a program using the Memory Modify (MM) command with the assembler/disassembler option.

1. Enter the program one source line at a time.
2. After each source line is entered, it is assembled and the object code is loaded to memory.

Refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for details on the 162Bug Assembler/Disassembler.

## Downloading an S-Record Object File

Another way to enter a program is to download an object file from a host system.

The program must be in S-record format (described in the *Debugging Package for Motorola 68K CISC CPUs User's Manual*) and may have been assembled or compiled on the host system.

Alternately, the program may have been previously created using the 162Bug MM command as outlined above and stored to the host using the Dump (DU) command.

A communication link must exist between the host system and port 2 on the MVME162LX. (Hardware configuration details are provided in *Installation and Startup* on page 3-3.) The file is downloaded from the host to MVME162LX memory by the Load (LO) command.

## Read the Program from Disk

Another way to enter a program is by reading the program from disk, using one of the disk commands (BO, BH, IOP). Once the object code has been loaded into memory, you can set breakpoints if desired and run the code or trace through it.

## Calling System Utilities from User Programs

A convenient way of doing character input/output and many other useful operations has been provided so that you do not have to write these routines into the target code. You can access various 162Bug routines via one of the MC68040 TRAP instructions, using vector #15. Refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for details on the various TRAP #15 utilities available and how to invoke them from within a user program.

## Preserving the Debugger Operating Environment

This section explains how to avoid contaminating the operating environment of the debugger. Topics covered include:

- ❑ 162Bug Vector Table and workspace
- ❑ Hardware functions
- ❑ Exception vectors used by 162Bug

162Bug uses certain of the MVME162LX onboard resources and may also use offboard system memory to contain temporary variables, exception vectors, etc. If you disturb resources upon which 162Bug depends, then the debugger may function unreliably or not at all.

If your application enables translation through the Memory Management Units (MMUs), and if your application utilizes resources of the debugger (e.g., system calls), your application must create the necessary translation tables for the debugger to have access to its various resources. The debugger honors the enabling of the MMUs; it does not disable translation.

## 162Bug Vector Table and Workspace

As described in the *Memory Requirements* section of Chapter 3, the 162Bug firmware needs 64KB of read/write memory to operate.

162Bug reserves ...	For ...
1024-byte area	A user program vector table area
1024-byte area	An exception vector table for the debugger itself to use
Space for static variables, and initializes these static variables to predefined default values.	
Space for the system stack, and initializes the system stack pointer to the top of this area.	

With the exception of the first 1024-byte vector table area, you must be extremely careful not to use the above-mentioned memory areas for other purposes.

Refer to the *Memory Requirements* section of Chapter 3 to determine how to dictate the location of the reserved memory areas.

### Examples

- ❑ If, for example, your program inadvertently wrote over the static variable area containing the serial communication parameters, these parameters would be lost, resulting in a loss of communication with the system console terminal.
- ❑ If your program corrupts the system stack, then an incorrect value may be loaded into the processor Program Counter (PC), causing a system crash.



## Hardware Functions

The only hardware resources used by the debugger are the EIA-232-D ports, which are initialized to interface to the debug terminal and a host. If these ports are reprogrammed, the terminal characteristics must be modified to suit, or the ports should be restored to the debugger-set characteristics prior to reinvoking the debugger.

## Exception Vectors Used by 162Bug

The exception vectors used by the debugger are listed below. These vectors must reside at the specified offsets in the target program's vector table for the associated debugger facilities (breakpoints, trace mode, etc.) to operate.

**Table 4-2. Exception Vectors Used by 162Bug**

Vector Offset	Exception	162Bug Facility
\$10	Illegal instruction	Breakpoints (used by <b>GO</b> , <b>GN</b> , <b>GT</b> )
\$24	Trace	Trace operations (such as <b>T</b> , <b>TC</b> , <b>TT</b> )
\$80-\$B8	TRAP #0 - #14	Used internally
\$BC	TRAP #15	System calls
\$ Note 1	Level 7 interrupt	ABORT pushbutton
\$ Note 2	Level 7 interrupt	AC Fail
\$DC	FP Unimplemented Data Type	Software emulation and data type conversion of floating point data.
Notes		
1. This depends on what the Vector Base Register (VBR) is set to in the MC2chip.		
2. This depends on what the Vector Base Register (VBR) is set to in the VMEchip2.		

When the debugger handles one of the exceptions listed in [Table 4-2](#), the target stack pointer is left pointing past the bottom of the exception stack frame created; that is, it reflects the system stack

pointer values just before the exception occurred. In this way, the operation of the debugger facility (through an exception) is transparent to users.

Example: Trace one instruction using the debugger firmware.

4

```
172-Bug>rd
```

```
PC      =00010000      SR      =2708=TR:OFF_S_7_N..      VBR      =00000000
SSP     =0000FFFC      USP     =00010000      SFC      =1=UD      DFC      =1=UD
CACR    =00000000=D: ....._B:..._I:...      PCR      =04310402
D0      =FFFFFFFF      D1      =00000000      D2      =00000000      D3      =00000000
D4      =00000000      D5      =00000000      D6      =00000000      D7      =00000000
A0      =00000000      A1      =00000000      A2      =00000000      A3      =00000000
A4      =00000000      A5      =00000000      A6      =00000000      A7      =0000FFFC
IPLR    =00000007      IML     =00000000      MMIE     =00000003      VIEN     =C0000000
R
VIST    =00000000      PIEN    =00002000      PIST     =00000000
00010000 203C0000 0001MOVE.L#$1,D0
```

```
172-Bug>t
```

```
PC      =00010006      SR      =2700=TR:OFF_S_7_.....      VBR      =00000000
SSP*    =0000FFFC      USP     =00010000      SFC      =1=UD      DFC      =1=UD
CACR    =00000000=D: ....._B:..._I:...      PCR      =04310402
D0      =00000001      D1      =00000000      D2      =00000000      D3      =00000000
D4      =00000000      D5      =00000000      D6      =00000000      D7      =00000000
A0      =00000000      A1      =00000000      A2      =00000000      A3      =00000000
A4      =00000000      A5      =00000000      A6      =00000000      A7      =0000FFFC
IPLR    =00000007      IML     =00000000      MMIE     =00000003      VIEN     =C0000000
R
VIST    =00000000      PIEN    =00002000      PIST     =00000000
00010006 D280 0001ADD.LD0,D1
```

```
172-Bug>
```

## Exception Vector Tables

Notice in the preceding example that the value of the target stack pointer register (A7) has not changed even though a trace exception has taken place. Your program may either use the exception vector table provided by 162Bug or it may create a separate exception vector table of its own. The two following sections detail these two methods.

### Using 162Bug Target Vector Table

The 162Bug initializes and maintains a vector table area for target programs. A target program is any program started by the bug:

- ❑ Manually with the **GO** command
- ❑ Manually with trace commands (**T**, **TC**, or **TT**)
- ❑ Automatically with the **BO** command.

The start address of this target vector table area is the base address (\$00) of the debugger memory. This address is loaded into the target-state VBR at power-up and cold-start reset and can be observed by using the **RD** command to display the target-state registers immediately after power-up.

The 162Bug initializes the target vector table with the debugger vectors listed in [Table 4-2 on page 4-13](#) and fills the other vector locations with the address of a generalized exception handler. The target program may take over as many vectors as desired by simply writing its own exception vectors into the table. If the vector locations listed in [Table 4-2](#) are overwritten, then the accompanying debugger functions are lost.

The 162Bug maintains a separate vector table for its own use. In general, you do not have to be aware of the existence of the debugger vector table. It is completely transparent and you should never make any modifications to the vectors that it contains.

## Creating a New Vector Table

Your program may create a separate vector table in memory to contain its exception vectors. If this is done, the program must change the value of the VBR to point at the new vector table. In order to use the debugger facilities you can copy the proper vectors from the 162Bug vector table into the corresponding vector locations in your program vector table.

The vector for the 162Bug generalized exception handler may be copied from offset \$08 (bus error vector) in the target vector table to all locations in your program vector table where a separate exception handler is not used. This provides diagnostic support in the event that your program is stopped by an unexpected exception. The generalized exception handler gives a formatted display of the target registers and identifies the type of the exception.

The following is an example of a routine which builds a separate vector table and then moves the VBR to point at it:

```

*
***  BUILDX - Build exception vector table ****
*
BUILDX  MOVEC.L  VBR,A0           Get copy of VBR.
        LEA     $10000,A1        New vectors at $10000.
        MOVE.L  $80(A0),D0       Get generalized exception vector.
        MOVE.W  $3FC,D1         Load count (all vectors).
LOOP    MOVE.L  D0,(A1,D1)       Store generalized exception vector.
        SUBQ.W  #4,D1
        BNE.B  LOOP            Initialize entire vector table.
        MOVE.L  $10(A0),$10(A1)  Copy breakpoints vector.
        MOVE.L  $24(A0),$24(A1)  Copy trace vector.
        MOVE.L  $BC(A0),$BC(A1)  Copy system call vector.
        LEA.L  COPROCC(PC),A2    Get your exception vector.
        MOVE.L  A2,$2C(A1)       Install as F-Line handler.
        MOVEC.L A1,VBR          Change VBR to new table.
        RTS
        END

```

It may turn out that your program uses one or more of the exception vectors that are required for debugger operation. Debugger facilities may still be used, however, if your exception handler can determine when to handle the exception itself and when to pass the exception to the debugger.

When an exception occurs which you want to pass on to the debugger (i.e., **ABORT**), your exception handler must read the vector offset from the format word of the exception stack frame. This offset is added to the address of the 162Bug target program vector table (which your program saved), yielding the address of the 162Bug exception vector. The program then jumps to the address stored at this vector location, which is the address of the 162Bug exception handler.

Your program must make sure that there is an exception stack frame in the stack and that it is exactly the same as the processor would have created for the particular exception before jumping to the address of the exception handler.

The following is an example of an exception handler which can pass an exception along to the debugger:

```
*
*** EXCEPT - Exception handler ***
*
EXCEPT SUBQ.L  #4,A7          Save space in stack for a PC value.
LINK     A6,#0          Frame pointer for accessing PC space.
MOVEM.L  A0-A5/D0-D7,-(SP)  Save registers.
:
: decide here if your code handles exception, if so, branch...
:
MOVE.L   BUFVBR,A0      Pass exception to debugger; Get saved VBR.
MOVE.W  14(A6),D0      Get the vector offset from stack frame.
AND.W   #$0FFF,D0      Mask off the format information.
MOVE.L  (A0,D0.W),4(A6) Store address of debugger exc handler.
MOVEM.L (SP)+,A0-A5/D0-D7 Restore registers.
UNLK    A6
RTS     Put addr of exc handler into PC and go.
```

## Floating Point Support

The floating point unit (FPU) of the MC68040 microprocessor chip is supported in 162Bug. The **MD**, **MM**, **RM**, and **RS** commands have been extended to allow display and modification of floating point data in registers and in memory. Floating point instructions can be assembled and disassembled with the **DI** option of the **MD** and **MM** commands.

**RM** and **RS** for floating point registers accept the floating point value in Double Precision Real Format or Scientific Notation.

Valid data types that can be used when modifying a floating point data register or a floating point memory location:

### Integer Data Types

---

12	Byte
1234	Word
12345678	Longword

### Floating Point Data Types

---

1_FF_7FFFFFFF	Single Precision Real Format
1_7FF_FFFFFFFFFFFFFF	Double Precision Real Format
-3.12345678901234501_E+123	Scientific Notation Format (decimal)

When entering data in single or double precision, you must observe the following rules:

1. The sign field is the first field and is a binary field.
2. The exponent field is the second field and is a hexadecimal field.
3. The mantissa field is the last field and is a hexadecimal field.

4. The sign field, the exponent field, and at least the first digit of the mantissa field must be present (any unspecified digits in the mantissa field are set to zero).
5. Each field must be separated from adjacent fields by an underscore.
6. All the digit positions in the sign and exponent fields must be present.

## Single Precision Real

This format would appear in memory as:

1-bit sign field	(1 binary digit)
8-bit biased exponent field	(2 hex digits. Bias = \$7F)
23-bit fraction field	(6 hex digits)

A single precision number takes 4 bytes in memory.

## Double Precision Real

This format would appear in memory as:

1-bit sign field	(1 binary digit)
11-bit biased exponent field	(3 hex digits. Bias = \$3FF)
52-bit fraction field	(13 hex digits)

A double precision number takes 8 bytes in memory.

**Note** The single and double precision formats have an implied integer bit (always 1).

## Scientific Notation

This format provides a convenient way to enter and display a floating point decimal number. Internally, the number is assembled into a packed decimal number and then converted into a number of the specified data type.

Entering data in this format requires the following fields:

- An optional sign bit (+ or -).
- One decimal digit followed by a decimal point.
- Up to 17 decimal digits (at least one must be entered).
- An optional Exponent field that consists of:
  - An optional underscore.
  - The Exponent field identifier, letter “E”.
  - An optional Exponent sign (+, -).
  - From 1 to 3 decimal digits.

For more information about the MC68040 floating point unit, refer to the *MC68040 Microprocessor User’s Manual*.

## The 162Bug Debugger Command Set

The 162Bug debugger commands are summarized in Table 4-3. The command syntax is shown using the symbols explained earlier in this chapter. The **CNFG** and **ENV** commands are explained in Appendix A. Controllers, devices, and their LUNs are listed in Appendix B or Appendix C. All other command details are explained in the *Debugging Package for Motorola 68K CISC CPUs User’s Manual*.



**Table 4-3. Debugger Commands**

Command Mnemonic	Title	Command Line Syntax
AB	Automatic Bootstrap Operating System	<b>AB</b> [ <i>V</i> ]
NOAB	No Autoboot	NOAB
AS	One Line Assembler	<b>AS</b> <i>addr</i>
BC	Block of Memory Compare	<b>BC</b> <i>range addr</i> [ <i>B</i>   <i>W</i>   <i>L</i> ]
BF	Block of Memory Fill	<b>BF</b> <i>range data</i> [ <i>increment</i> ] [ <i>B</i>   <i>W</i>   <i>L</i> ]
BH	Bootstrap Operating System and Halt	<b>BH</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>string</i> ]
BI	Block of Memory Initialize	<b>BI</b> <i>range</i> [ <i>B</i>   <i>W</i>   <i>L</i> ]
BM	Block of Memory Move	<b>BM</b> <i>range addr</i> [ <i>B</i>   <i>W</i>   <i>L</i> ]
BO	Bootstrap Operating System	<b>BO</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>string</i> ]
BR	Breakpoint Insert	<b>BR</b> [ <i>addr</i> [ <i>:count</i> ]]
NOBR	Breakpoint Delete	<b>NOBR</b> [ <i>addr</i> ]
BS	Block of Memory Search	<b>BS</b> <i>range text</i> [ <i>B</i>   <i>W</i>   <i>L</i> ] or <b>BS</b> <i>range data</i> [ <i>mask</i> ] [ <i>B</i>   <i>W</i>   <i>L</i> ] [ <i>N</i> ] [ <i>V</i> ]
BV	Block of Memory Verify	<b>BV</b> <i>range data</i> [ <i>increment</i> ] [ <i>B</i>   <i>W</i>   <i>L</i> ]
CM	Concurrent Mode	<b>CM</b> [[ <i>port</i> ] [ <i>ID-string</i> ] [ <i>baud</i> ] [ <i>phone-number</i> ]]   [ <i>A</i> ]   [ <i>H</i> ]
NOCM	No Concurrent Mode	NOCM
CNFG	Configure Board Information Block	<b>CNFG</b> [ <i>I</i> ][ <i>M</i> ]
CS	Checksum	<b>CS</b> <i>range</i> [ <i>B</i>   <i>W</i>   <i>L</i> ]
DC	Data Conversion	<b>DC</b> <i>exp</i>   <i>addr</i> [ <i>B</i> ][ <i>O</i> ][ <i>A</i> ]
DMA	DMA Block of Memory Move	<b>DMA</b> <i>range addr vdir am blk</i> [ <i>B</i>   <i>W</i>   <i>L</i> ]
DS	One Line Disassembler	<b>DS</b> <i>addr</i> [ <i>:count</i>   <i>addr</i> ]
DU	Dump S-records	<b>DU</b> [ <i>port</i> ] <i>range</i> [ <i>text</i> ] [ <i>addr</i> ] [ <i>offset</i> ] [ <i>B</i>   <i>W</i>   <i>L</i> ]

**Table 4-3. Debugger Commands (Continued)**

<b>Command Mnemonic</b>	<b>Title</b>	<b>Command Line Syntax</b>
ECHO	Echo String	<b>ECHO</b> [ <i>port</i> ] { <i>hexadecimal number</i> } {' <i>string</i> '}
ENV	Set Environment to Bug/Operating System	<b>ENV</b> [; [ <i>D</i> ]]
GD	Go Direct (Ignore Breakpoints)	<b>GD</b> [ <i>addr</i> ]
GN	Go to Next Instruction	GN
GO	Go Execute User Program	<b>GO</b> [ <i>addr</i> ]
GT	Go to Temporary Breakpoint	<b>GT</b> <i>addr</i>
HE	Help	<b>HE</b> [ <i>command</i> ]
IOC	I/O Control for Disk	IOC
IOI	I/O Inquiry	<b>IOI</b> [; [ <i>C</i>   <i>L</i> ]]
IOP	I/O Physical (Direct Disk Access)	IOP
IOT	I/O "TEACH" for Configuring Disk Controller	<b>IOT</b> [; [ <i>A</i>   <i>F</i>   <i>H</i>   <i>T</i> ]]
IRQM	Interrupt Request Mask	<b>IRQM</b> [ <i>mask</i> ]
LO	Load S-records from Host	<b>LO</b> [ <i>port</i> ] [ <i>addr</i> ] [; [ <i>XI</i>   <i>IC</i>   <i>IT</i> ]] [= <i>text</i> ]
MA	Macro Define/Display	<b>MA</b> [ <i>name</i>  ; <i>L</i> ]
NOMA	Macro Delete	<b>NOMA</b> [ <i>name</i> ]
MAE	Macro Edit	<b>MAE</b> <i>name line#</i> [ <i>string</i> ]
MAL	Enable Macro Expansion Listing	MAL
NOMAL	Disable Macro Expansion Listing	NOMAL
MAW	Save Macros	<b>MAW</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>del block #</i> ]
MAR	Load Macros	<b>MAR</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>del block #</i> ]
MD	Memory Display	<b>MD</b> [ <i>S</i> ] <i>addr</i> [: <i>count</i>   <i>addr</i> ] [; [ <i>B</i>   <i>W</i>   <i>L</i>   <i>S</i>   <i>D</i>   <i>DI</i> ]]

Table 4-3. Debugger Commands (Continued)

Command Mnemonic	Title	Command Line Syntax
MENU	Menu	MENU
MM	Memory Modify	<b>MM</b> <i>addr</i> [; [[ <b>B</b>   <b>W</b>   <b>L</b>   <b>S</b>   <b>D</b> ] [ <b>A</b> ] [ <b>N</b> ]]   [ <b>DI</b> ]]
MMD	Memory Map Diagnostic	<b>MMD</b> <i>range increment</i> [; <b>B</b>   <b>W</b>   <b>L</b> ]
MS	Memory Set	<b>MS</b> <i>addr</i> { <i>hexadecimal number</i> } {' <i>string</i> '}
MW	Memory Write	<b>MW</b> <i>addr data</i> [; <b>B</b>   <b>W</b>   <b>L</b> ]
NAB	Automatic Network Boot Operating System	NAB
NBH	Network Boot Operating System and Halt	<b>NBH</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>client IP Address</i> ] [ <i>server IP Address</i> ] [ <i>string</i> ]
NBO	Network Boot Operating System	<b>NBO</b> [ <i>controller LUN</i> ] [ <i>device LUN</i> ] [ <i>client IP Address</i> ] [ <i>server IP Address</i> ] [ <i>string</i> ]
NIOC	Network I/O Control	NIOC
NIOP	Network I/O Physical	NIOP
NIOT	Network I/O Teach	<b>NIOT</b> [; [ <b>H</b> ]   [ <b>A</b> ]]
NPING	Network Ping	<b>NPING</b> <i>controller-LUN device-LUN source-IP destination-IP</i> [ <i>n-packets</i> ]
OF	Offset Registers Display / Modify	<b>OF</b> [ <b>Rn</b> [; <b>A</b> ]]
PA	Printer Attach	<b>PA</b> [ <i>port</i> ]
NOPA	Printer Detach	<b>NOPA</b> [ <i>port</i> ]
PF	Port Format	<b>PF</b> [ <i>port</i> ]
NOPF	Port Detach	<b>NOPF</b> [ <i>port</i> ]
PFLASH	Program FLASH Memory	<b>PFLASH</b> <i>SSADDR SEADDR DSADDR</i> [ <i>IEADDR</i> ] [; [ <b>A</b>   <b>R</b> ] [ <b>X</b> ]] or <b>PFLASH</b> <i>SSADDR:COUNT DSADDR</i> [ <i>IEADDR</i> ] [; [ <b>B</b>   <b>W</b>   <b>L</b> ] [ <b>A</b>   <b>R</b> ] [ <b>X</b> ]]
PS	Put RTC Into Power Save Mode for Storage	PS

**Table 4-3. Debugger Commands (Continued)**

Command Mnemonic	Title	Command Line Syntax
RB	ROMboot Enable	<b>RB</b> [ <i>V</i> ]
NORB	ROMboot Disable	NORB
RD	Register Display	<b>RD</b> {[+ - =] [ <i>dname</i> ] [/]} {[+ - =] [ <i>reg1</i> [- <i>reg2</i> ] [/]} [ <i>E</i> ]
REMOTE	Connect the Remote Modem to CSO	REMOTE
RESET	Cold/Warm Reset	RESET
RL	Read Loop	<b>RL</b> <i>addr</i> ; [ <b>B</b>   <b>W</b>   <b>L</b> ]
RM	Register Modify	<b>RM</b> [ <i>reg</i> ]
RS	Register Set	<b>RS</b> <i>reg</i> [ <i>exp</i>   <i>addr</i> ]
SD	Switch Directories	SD
SET	Set Time and Date	<b>SET</b> <i>mmddyymm   n</i> ; <b>C</b>
SYM	Symbol Table Attach	<b>SYM</b> [ <i>addr</i> ]
NOSYM	Symbol Table Detach	NOSYM
SYMS	Symbol Table Display/Search	<b>SYMS</b> [ <i>symbol-name</i> ]   [ <i>S</i> ]
T	Trace	<b>T</b> [ <i>count</i> ]
TA	Terminal Attach	<b>TA</b> [ <i>port</i> ]
TC	Trace on Change of Control Flow	<b>TC</b> [ <i>count</i> ]
TIME	Display Time and Date	<b>TIME</b> [ <i>;</i> [ <b>C</b>   <b>L</b>   <b>O</b> ]]
TM	Transparent Mode	<b>TM</b> [ <i>port</i> ] [ <b>ESCAPE</b> ]
TT	Trace to Temporary Breakpoint	<b>TT</b> <i>addr</i>
VE	Verify S-Records Against Memory	<b>VE</b> [ <i>port</i> ] [ <i>addr</i> ] [ <i>;</i> [ <b>X</b> ][ <b>C</b> ]] [= <i>text</i> ]
VER	Display Revision/Version	<b>VER</b> [ <i>;</i> <b>E</b> ]
WL	Write Loop	<b>WL</b> <i>addr data</i> [ <i>;</i> <b>B</b>   <b>W</b>   <b>L</b> ]

## Configure Board Information Block

**CNFG** [;[I][M]]

This command is used to display and configure the board information block. This block is resident within the Non-Volatile RAM (NVRAM). Refer to the *Debugging Package for Motorola 68K CISC CPUs User's Manual* for the actual location. The information block contains various elements detailing specific operation parameters of the hardware. The *Debugging Package for Motorola 68K CISC CPUs User's Manual* describes the elements within the board information block, and lists the size and logical offset of each element. The **CNFG** command does *not* describe the elements and their use. The board information block contents are checksummed for validation purposes. This checksum is the last element of the block.

Although the factory fills all fields except the IndustryPack fields, only these fields **MUST** contain correct information:

- ❑ MPU clock speed
- ❑ Ethernet address
- ❑ Local SCSI identifier

The board structure for the 700/800-series MVME162LX is as follows:

```
162-Bug>cnfg
Board (PWA) Serial Number = "      "
Board Identifier = "      "
Artwork (PWA) Identifier = "      "
MPU Clock Speed = "3200 "
Ethernet Address = 08003E200000
Local SCSI Identifier = "07 "
Parity Memory Mezzanine Artwork (PWA) Identifier = "      "
```

```

Parity Memory Mezzanine (PWA) Serial Number = "      "
Static Memory Mezzanine Artwork (PWA) Identifier = "      "
Static Memory Mezzanine (PWA) Serial Number = "      "
ECC Memory Mezzanine #1 Artwork (PWA) Identifier = "      "
ECC Memory Mezzanine #1 (PWA) Serial Number = "      "
ECC Memory Mezzanine #2 Artwork (PWA) Identifier = "      "
ECC Memory Mezzanine #2 (PWA) Serial Number = "      "
Serial Port 2 Personality Artwork (PWA) Identifier = "      "
Serial Port 2 Personality Module (PWA) Serial Number = "      "
IndustryPack A Board Identifier = "      "
IndustryPack A (PWA) Serial Number = "      "
IndustryPack A Artwork (PWA) Identifier = "      "
IndustryPack B Board Identifier = "      "
IndustryPack B (PWA) Serial Number = "      "
IndustryPack B Artwork (PWA) Identifier = "      "
IndustryPack C Board Identifier = "      "
IndustryPack C (PWA) Serial Number = "      "
IndustryPack C Artwork (PWA) Identifier = "      "
IndustryPack D Board Identifier = "      "
IndustryPack D (PWA) Serial Number = "      "
IndustryPack D Artwork (PWA) Identifier = "      "
162-Bug>

```

Note that the parameters that are quoted are left-justified character (ASCII) strings padded with space characters, and the quotes (") are displayed to indicate the size of the string. Parameters that are not quoted are considered data strings, and data strings are right-justified. The data strings are padded with zeros if the length is not met.

In the event of corruption of the board information block, the command displays a question mark ( ? ) for nondisplayable characters. A warning message (WARNING: Board Information Block Checksum Error) is also displayed in the event of a checksum failure.

Using the I option initializes the unused area of the board information block to zero.

Modification is possible through use of the command's **M** option. At the end of the modification session, you are prompted for the update to Non-Volatile RAM (NVRAM). A **y** response must be made for the update to occur; any other response terminates the update (disregards all changes). The update also recalculates the checksum.

Be cautious when modifying parameters. Some of these parameters are set up by the factory, and correct board operation relies upon these parameters.

Once modification/update is complete, you can display the current contents as described earlier.

## Set Environment to Bug/Operating System

**ENV** [;[**D**]]

The **ENV** command allows you to interactively view/configure all Bug operational parameters that are kept in battery-backed-up RAM (BBRAM), also known as non-volatile RAM (NVRAM). The operational parameters are saved in NVRAM and used whenever power is lost.

Whenever the Bug uses a parameter from NVRAM, the NVRAM contents are first tested by checksum to insure the integrity of the NVRAM contents. In the instance of BBRAM checksum failure, certain default values are assumed as stated below.

The bug operational parameters (which are kept in NVRAM) are not initialized automatically on power up/warm reset. It is up to the Bug user to invoke the **ENV** command. Once the **ENV** command is invoked and executed without error, Bug default and/or user parameters are loaded into NVRAM along with checksum data. If any of the operational parameters have been modified, the new parameters do not go into effect until a reset/powerup condition occurs. Should you determine that the NVRAM contents have been corrupted, use a double-button reset (described under *Restarting the System* in Chapter 3) to reinitialize the system.

If the **ENV** command is invoked with no options on the command line, you are prompted to configure all operational parameters. If the **ENV** command is invoked with the option **D**, ROM defaults will be loaded into NVRAM.

The parameters to be configured are listed in the following table.

**Table A-1. ENV Command Parameters**

ENV Parameter and Options	Default	Meaning of Default
Bug or System environment [B/S]	B	Bug mode
Field Service Menu Enable [Y/N]	N	Do not display field service menu.
Remote Start Method Switch [G/M/B/N]	B	Use both the Global Control and Status Register (GCSR) in the VMEchip2, and the Multiprocessor Control Register (MPCR) in shared RAM, methods to pass and start execution of cross-loaded programs.
Probe System for Supported I/O Controllers [Y/N]	Y	Accesses will be made to the appropriate system busses (e.g., VMEbus, local MPU bus) to determine presence of supported controllers.
Negate VMEbus SYSFAIL* Always [Y/N]	N	Negate VMEbus SYSFAIL after successful completion or entrance into the bug command monitor.
Local SCSI Bus Reset on Debugger Startup [Y/N]	N	Local SCSI bus is not reset on debugger startup.
Local SCSI Bus Negotiations Type [A/S/N]	A	Asynchronous negotiations.
Industry Pack Reset on Debugger Startup [Y/N]	Y	Industry Pack(s) is/are reset on debugger startup.
Ignore CFGA Block on a Hard Disk Boot [Y/N]	Y	Enable the ignorance of the Configuration Area (CFGA) Block (hard disk only).
Auto Boot Enable [Y/N]	N	Auto Boot function is disabled.



**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
Auto Boot at power-up only [Y/N]	Y	Auto Boot is attempted at power-up reset only.
Auto Boot Controller LUN	00	LUN of a disk/tape controller module currently supported by the Bug. Default is \$0.
Auto Boot Device LUN	00	LUN of a disk/tape device currently supported by the Bug. Default is \$0.
Auto Boot Abort Delay	15	The time in seconds that the Auto Boot sequence will delay before starting the boot. The purpose for the delay is to allow you the option of stopping the boot by use of the Break key. The time value is from 0 through 255 seconds.
Auto Boot Default String [Y(NULL String)/(String)]		You may specify a string (filename) which is passed on to the code being booted. Maximum length is 16 characters. Default is the null string.
ROM Boot Enable [Y/N]	N	ROMboot function is disabled.
ROM Boot at power-up only [Y/N]	Y	ROMboot is attempted at power up only.
ROM Boot Enable search of VMEbus [Y/N]	N	VMEbus address space will not be accessed by ROMboot.
ROM Boot Abort Delay	00	The time in seconds that the ROMboot sequence will delay before starting the boot. The purpose for the delay is to allow you the option of stopping the boot by use of the Break key. The time value is from 0 through 255 seconds.
ROM Boot Direct Starting Address	FF800000	First location tested when the Bug searches for a ROMboot Module.
ROM Boot Direct Ending Address	FFDFFFFC	Last location tested when the Bug searches for a ROMboot Module.

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
Network Auto Boot Enable [Y/N]	N	Network Auto Boot function is disabled.
Network Auto Boot at power-up only [Y/N]	Y	Network Auto Boot is attempted at power up reset only.
Network Auto Boot Controller LUN	00	LUN of a disk/tape controller module currently supported by the Bug. Default is \$0.
Network Auto Boot Device LUN	00	LUN of a disk/tape device currently supported by the Bug. Default is \$0.
Network Auto Boot Abort Delay	5	The time in seconds that the Network Boot sequence will delay before starting the boot. The purpose for the delay is to allow you the option of stopping the boot by use of the Break key. The time value is from 0 through 255 seconds.
Network Autoboot Configuration Parameters Pointer (NVRAM)	00000000	The address where the network interface configuration parameters are to be saved/retained in NVRAM; these parameters are the necessary parameters to perform an unattended network boot.
Memory Search Starting Address	00000000	Where the Bug begins to search for a work page (a 64KB block of memory) to use for vector table, stack, and variables. This must be a multiple of the debugger work page, modulo \$10000 (64KB). In a multi-162 environment, each MVME162LX board could be set to start its work page at a unique address to allow multiple debuggers to operate simultaneously.

**Table A-1. ENV Command Parameters (Continued)**

<b>ENV Parameter and Options</b>	<b>Default</b>	<b>Meaning of Default</b>
Memory Search Ending Address	00100000	Top limit of the Bug's search for a work page. If a contiguous block of memory, 64KB in size, is not found in the range specified by Memory Search Starting Address and Memory Search Ending Address parameters, then the bug will place its work page in the onboard static RAM on the MVME162LX. Default Memory Search Ending Address is the calculated size of local memory.
Memory Search Increment Size	00010000	A multi-CPU feature used to offset the location of the Bug work page. This must be a multiple of the debugger work page, modulo \$10000 (64KB). Typically, Memory Search Increment Size is the product of CPU number and size of the Bug work page. Example: first CPU \$0 (0 x \$10000), second CPU \$10000 (1 x \$10000), etc.
Memory Search Delay Enable [Y/N]	N	No delay before the Bug begins its search for a work page.

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
Memory Search Delay Address	FFFFD20F	Default address is \$FFFFD20F. This is the MVME162LX GCSR (global control/ status register) GPCSR0 as accessed through VMEbus A16 space. It is assumed that the MVME162LX GRPAD (group address) and BDAD (board address within group) switches are set to "on". This byte-wide value is initialized to \$FF by MVME162LX hardware after a System or Power-on Reset. In a multi-162 environment, where the work pages of several Bugs will reside in the memory of the primary (first) MVME162LX, the non-primary CPUs will wait for the data at the Memory Search Delay Address to be set to \$00, \$01, or \$02 (refer to the <i>Memory Requirements</i> section in Chapter 3 for the definition of these values) before attempting to locate their work page in the memory of the primary CPU.
Memory Size Enable [Y/N]	Y	Memory will be sized for Self Test diagnostics.
Memory Size Starting Address	00000000	Default Starting Address is \$0.
Memory Size Ending Address	00100000	Default Ending Address is the calculated size of local memory.

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
<p>Memory Configuration Defaults:</p> <p>The default configuration for Dynamic RAM mezzanine boards will position the mezzanine with the largest memory size to start at the address selected with the ENV parameter "Base Address of Dynamic Memory". The Base Address parameter defaults to 0. The smaller sized mezzanine will follow immediately above the larger in the memory map. If mezzanines of the same size and type are present, the first (closest to the board) is mapped to the selected base address. If mezzanines of same size but with different type (parity and ECC) are present, the parity type will be mapped to the selected base address and the ECC type mezzanine will follow. The SRAM does not default to a location in the memory map that is contiguous with Dynamic RAM.</p>		
Base Address of Dynamic Memory	00000000	Beginning address of Dynamic Memory (Parity and/or ECC type memory). It must be a multiple of the Dynamic Memory board size, starting with 0. Default is \$0.
Size of Parity Memory	00100000	This is the size of the Parity type dynamic RAM mezzanine, if any. The default is the calculated size of the Dynamic memory mezzanine board.
Size of ECC Memory Board 0	00000000	This is the size of the first ECC type memory mezzanine. The default is the calculated size of the memory mezzanine.
Size of ECC Memory Board 1	00000000	This is the size of the second ECC type memory mezzanine. The default is the calculated size of the memory mezzanine.
Base Address of Static Memory	FFE00000	This is the beginning address of SRAM. The default is FFE00000 for the onboard 128KB SRAM, or E1000000 for the 2MB SRAM mezzanine. If only 2MB SRAM is present, it defaults to address 00000000.
Size of Static Memory	00080000	This is the size of the SRAM type memory present. The default is the calculated size of the onboard SRAM or an SRAM type mezzanine.

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
<p>ENV asks the following series of questions to set up the VMEbus interface for the MVME162LX modules. You should have a working knowledge of the VMEchip2 as given in the <i>MVME162LX Embedded Controller Programmer's Reference Guide</i> in order to perform this configuration. Also included in this series are questions for setting ROM and Flash access time.</p> <p>The slave address decoders are used to allow another VMEbus master to access a local resource of the MVME162LX. There are two slave address decoders set. They are set up as follows:</p>		
Slave Enable #1 [Y/N]	Y	Yes, set up and enable Slave Address Decoder #1.
Slave Starting Address #1	00000000	Base address of the local resource that is accessible by the VMEbus. Default is the base of local memory, \$0.
Slave Ending Address #1	000FFFFFF	Ending address of the local resource that is accessible by the VMEbus. Default is the end of calculated memory.
Slave Address Translation Address #1	00000000	Register that allows the VMEbus address and the local address to be different. The value in this register is the base address of local resource that is associated with the starting and ending address selection from the previous questions. Default is 0.
Slave Address Translation Select #1	00000000	Register that defines which bits of the address are significant. A logical one "1" denotes significant address bits, a logical zero "0" non-significant bits. Default is 0.
Slave Control #1	03FF	Defines the access restriction for the address space defined with this slave address decoder. Default is \$03FF.
Slave Enable #2 [Y/N]	N	Do not set up and enable Slave Address Decoder #2.
Slave Starting Address #2	00000000	Base address of the local resource that is accessible by the VMEbus. Default is 0.

**Table A-1. ENV Command Parameters (Continued)**

<b>ENV Parameter and Options</b>	<b>Default</b>	<b>Meaning of Default</b>
Slave Ending Address #2	00000000	Ending address of the local resource that is accessible by the VMEbus. Default is 0.
Slave Address Translation Address #2	00000000	Works the same as Slave Address Translation Address #1. Default is 0.
Slave Address Translation Select #2	00000000	Works the same as Slave Address Translation Select #1. Default is 0.
Slave Control #2	0000	Defines the access restriction for the address space defined with this slave address decoder. Default is \$0000.
Master Enable #1 [Y/N]	Y	Yes, set up and enable the Master Address Decoder #1.
Master Starting Address #1	02000000	Base address of the VMEbus resource that is accessible from the local bus. Default is the end of calculated local memory, unless memory is less than 16MB, then this register will always be set to 01000000.
Master Ending Address #1	FFFFFFF	Ending address of the VMEbus resource that is accessible from the local bus. Default is the end of calculated memory.
Master Control #1	0D	Defines the access characteristics for the address space defined with this master address decoder. Default is \$0D.
Master Enable #2 [Y/N]	N	Do not set up and enable the Master Address Decoder #2.
Master Starting Address #2	00000000	Base address of the VMEbus resource that is accessible from the local bus. Default is \$00000000.
Master Ending Address #2	00000000	Ending address of the VMEbus resource that is accessible from the local bus. Default is \$00000000.

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
Master Control #2	00	Defines the access characteristics for the address space defined with this master address decoder. Default is \$00.
Master Enable #3 [Y/N]	Y/N (Depends on calculated size of local RAM)	Yes, set up and enable the Master Address Decoder #3. This is the default if the board contains less than 16MB of calculated RAM. Do not set up and enable the Master Address Decoder #3. This is the default for boards containing at least 16MB of calculated RAM.
Master Starting Address #3	00000000	Base address of the VMEbus resource that is accessible from the local bus. If enabled, the value is calculated as one more than the calculated size of memory. If not enabled, the default is \$00000000.
Master Ending Address #3	00000000	Ending address of the VMEbus resource that is accessible from the local bus. If enabled, the default is \$00FFFFFF, otherwise \$00000000.
Master Control #3	00	Defines the access characteristics for the address space defined with this master address decoder. If enabled, the default is \$3D, otherwise \$00.
Master Enable #4 [Y/N]	N	Do not set up and enable the Master Address Decoder #4.
Master Starting Address #4	00000000	Base address of the VMEbus resource that is accessible from the local bus. Default is \$0.
Master Ending Address #4	00000000	Ending address of the VMEbus resource that is accessible from the local bus. Default is \$0.



**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
Master Address Translation Address #4	00000000	Allows the VMEbus address and the local address to differ. The value in this register is the base address of the VMEbus resource that is associated with the starting and ending address selection from the previous questions. Default is 0.
Master Address Translation Select #4	00000000	Defines which bits of the address are significant. A logical 1 indicates significant address bits, logical 0 is non-significant. Default is 0.
Master Control #4	00	Defines the access characteristics for the address space defined with this master address decoder. Default is \$00.
Short I/O (VMEbus A16) Enable [Y/N]	Y	Yes, enable the Short I/O Address Decoder.
Short I/O (VMEbus A16) Control	01	Defines the access characteristics for the address space defined with the Short I/O address decoder. Default is \$01.
F-Page (VMEbus A24) Enable [Y/N]	Y	Yes, enable the F-Page Address Decoder.
F-Page (VMEbus A24) Control	02	Defines the access characteristics for the address space defined with the F-Page address decoder. Default is \$02.
ROM Access Time Code	04	Defines the ROM access time. The default is \$04, which sets an access time of five clock cycles of the local bus.
Flash Access Time Code	03	Defines the Flash access time. The default is \$03, which sets an access time of four clock cycles of the local bus.
MCC Vector Base	05	Base interrupt vector for the component specified. Default: MC2chip = \$05, VMEchip2 Vector 1 = \$06, VMEchip2 Vector 2 = \$07.
VMEC2 Vector Base #1	06	
VMEC2 Vector Base #2	07	

**Table A-1. ENV Command Parameters (Continued)**

ENV Parameter and Options	Default	Meaning of Default
VMEC2 GCSR Group Base Address	D2	Specifies the group address (\$FFFFXX00) in Short I/O for this board. Default = \$D2.
VMEC2 GCSR Board Base Address	00	Specifies the base address (\$FFFFD2XX) in Short I/O for this board. Default = \$00.
VMEbus Global Time Out Code	01	Controls the VMEbus timeout when the MVME162LX is operating as system controller. Default \$01 = 64 $\mu$ s.
Local Bus Time Out Code	02	Controls the local bus timeout. Default \$02 = 256 $\mu$ s.
VMEbus Access Time Out Code	02	Controls the local bus to VMEbus access timeout. Default \$02 = 32 ms.

## Configuring the IndustryPacks

ENV asks the following series of questions to set up IndustryPacks (IPs) on MVME162LX VMEmodules.

The *MVME162LX Embedded Controller Programmer's Reference Guide* describes the base addresses and the IP register settings. Refer to that manual for information on setting base addresses and register bits.

**Note** The IP2 ASIC on the MVME162LX supports up to four IndustryPack (IP) interfaces, designated IP\_a through IP\_d. The 700/800-series MVME162LX itself accommodates two IPs: IP\_a and IP\_b. In the following discussion, the segments applicable to IP\_c and IP\_d are not used in the 700/800-series MVME162LX.

```
IP A Base Address      = 00000000?
IP B Base Address      = 00000000?
IP C Base Address      = 00000000?
IP D Base Address      = 00000000?
```

Base address for mapping IP modules. Only the upper 16 bits are significant.

IP D/C/B/A Memory Size = 00000000?

Define the memory size requirements for the IP modules:

Bits	IP	Register Address
31-24	D	FFFBC00F
23-16	C	FFFBC00E
15-08	B	FFFBC00D
07-00	A	FFFBC00C

IP D/C/B/A General Control = 00000000?

Define the general control requirements for the IP modules:

Bits	IP	Register Address
31-24	D	FFFBC01B
23-16	C	FFFBC01A
15-08	B	FFFBC019
07-00	A	FFFBC018

IP D/C/B/A Interrupt 0 Control = 00000000?

Define the interrupt control requirements for the IP modules channel 0:

Bits	IP	Register Address
31-24	D	FFFBC016
23-16	C	FFFBC014
15-08	B	FFFBC012
07-00	A	FFFBC010

IP D/C/B/A Interrupt 1 Control = 00000000?

Define the interrupt control requirements for the IP modules channel 1:

Bits	IP	Register Address
31-24	D	FFFBC017
23-16	C	FFFBC015
15-08	B	FFFBC013
07-00	A	FFFBC011



### Caution

Before environment parameters are saved in the NVRAM, a warning message will appear if you have specified environment parameters that will cause an overlap condition. The important information about each configurable element in the memory map is displayed, showing where any overlap conditions exist. This will allow you to quickly identify and correct an undesirable configuration before it is saved.

## ENV warning example:

WARNING: Memory MAP Overlap Condition Exists

S-Address	E-Address	Enable	Overlap	M-Type	Memory-MAP-Name
\$00000000	\$FFFFFFFF	Yes	Yes	Master	Local Memory (Dynamic RAM)
\$FFE00000	\$FFE7FFFF	Yes	Yes	Master	Static RAM
\$01000000	\$EFFFFFFF	Yes	Yes	Master	VMEbus Master #1
\$00000000	\$00000000	No	No	Master	VMEbus Master #2
\$00000000	\$00FFFFFF	Yes	Yes	Master	VMEbus Master #3
\$00000000	\$00000000	No	No	Master	VMEbus Master #4
\$F0000000	\$FF7FFFFF	Yes	Yes	Master	VMEbus F Pages (A24/A32)
\$FFFF0000	\$FFFFFFF	Yes	Yes	Master	VMEbus Short I/O (A16)
\$FF800000	\$FFBFFFFF	Yes	Yes	Master	Flash/PROM
\$FFF00000	\$FFFFFFF	Yes	Yes	Master	Local I/O
\$00000000	\$00000000	No	No	Master	Industry Pack A
\$00000000	\$00000000	No	No	Master	Industry Pack B
\$00000000	\$00000000	No	No	Master	Industry Pack C
\$00000000	\$00000000	No	No	Master	Industry Pack D
\$00000000	\$00000000	No	No	Slave	VMEbus Slave #1
\$00000000	\$00000000	No	No	Slave	VMEbus Slave #2



# Disk/Tape Controller Data

**B**

## Disk/Tape Controller Modules Supported

The following VMEbus disk/tape controller modules are supported by the 162Bug. The default address for each controller type is First Address and the controller can be addressed by First CLUN during commands **BH**, **BO**, or **IOP**, or during TRAP #15 calls .DSKRD or .DSKWR. Note that if another controller of the same type is used, the second one must have its address changed by its onboard jumpers and/or switches, so that it matches the "Second Address" value and can be called up by the "Second CLUN" value.

Controller Type	First CLUN	First Address	Second CLUN	Second Address
CISC Embedded Controller	\$00*	--	--	--
MVME328 - SCSI Controller 1	\$06	\$FFFF9000	\$07	\$FFFF9800
MVME328 - SCSI Controller 2	\$16	\$FFFF4800	\$17	\$FFFF5800
MVME328 - SCSI Controller 3	\$18	\$FFFF7000	\$19	\$FFFF7800

\*If an MVME162LX with an SCSI port is used, that board has CLUN 0.

## Disk/Tape Controller Default Configurations

**Note** SCSI Common Command Set (CCS) devices are the only ones tested by Motorola Computer Group.

### CISC Embedded Controllers -- 7 Devices

Controller LUN	Address	Device LUN	Device Type
0	\$XXXXXXXX	00	SCSI Common Command Set
		10	(CCS), which may be any of these:
		20	- Fixed direct access
		30	- Removable flexible direct access
		40	(TEAC style)
		50	- CD-ROM
		60	- Sequential access



## MVME328 -- 14 Devices

Controller LUN	Address	Device LUN	Device Type
6	\$FFFF9000	00 08	SCSI Common Command Set (CCS), which may be any of these: - Removable flexible direct access (TEAC style) - CD-ROM - Sequential access
7	\$FFFF9800	10 18	
16	\$FFFF4800	20 28 30	
17	\$FFFF5800	40 48	
18	\$FFFF7000	50 58	Same as above, but these are only available if the daughter card for the second SCSI channel is present.
19	\$FFFF7800	60 68 70	

## IOT Command Parameters for Supported Floppy Types

The following table lists the proper IOT command parameters for floppies used with boards such as the MVME328 and MVME162LX.

IOT Parameter	Floppy Types and Formats						
	DSDD5	PCXT8	PCXT9	PCXT9_3	PCAT	PS2	SHD
Sector Size 0- 128 1- 256 2- 512 3-1024 4-2048 5-4096 =	1	2	2	2	2	2	2
Block Size: 0- 128 1- 256 2- 512 3-1024 4-2048 5-4096 =	1	1	1	1	1	1	1
Sectors/Track	10	8	9	9	F	12	24
Number of Heads =	2	2	2	2	2	2	2
Number of Cylinders =	50	28	28	50	50	50	50
Precomp. Cylinder =	50	28	28	50	50	50	50
Reduced Write Current Cylinder =	50	28	28	50	50	50	50
Step Rate Code =	0	0	0	0	0	0	0
Single/Double DATA Density =	D	D	D	D	D	D	D
Single/Double TRACK Density =	D	D	D	D	D	D	D
Single/Equal_in_all Track Zero Density =	S	E	E	E	E	E	E
Slow/Fast Data Rate =	S	S	S	S	F	F	F
Other Characteristics							
Number of Physical Sectors	0A00	0280	02D0	05A0	0960	0B40	1680

IOT Parameter	Floppy Types and Formats						
	DSDD5	PCXT8	PCXT9	PCXT9_3	PCAT	PS2	SHD
Number of Logical Blocks (100 in size)	09F8	0500	05A0	0B40	12C0	1680	2D00
Number of Bytes in Decimal	653312	327680	368460	737280	1228800	1474560	2949120
Media Size/Density	5.25/DD	5.25/DD	5.25/DD	3.5/DD	5.25/HD	3.5/HD	3.5/ED
<b>Notes</b>							
1. All numerical parameters are in hexadecimal format unless otherwise noted.							
2. The DSDD5 type floppy is the default setting for the debugger.							

**B**

**B**

## Network Controller Modules Supported

The following VMEbus network controller modules are supported by the MVME162BUG firmware. The default address for each type and position is showed to indicate where the controller must reside to be supported by MVME162BUG. The controllers are accessed via the specified CLUN and DLUNs listed here. The CLUN and DLUN are used in conjunction with the debugger commands **NBH**, **NBO**, **NIOP**, **NIOC**, **NIOT**, **NPING**, and **NAB**, and also with the debugger system calls **.NETRD**, **.NETWR**, **.NETFOPN**, **.NETFRD**, **.NETCFG**, and **.NETCTRL**.

Controller Type	CLUN	DLUN	Address	Interface Type
MVME162	\$00	\$00	FFFF46000	Ethernet
MVME376 #1	\$02	\$00	FFFFF1200	Ethernet
MVME376 #2	\$03	\$00	FFFFF1400	Ethernet
MVME376 #3	\$04	\$00	FFFFF1600	Ethernet
MVME376 #4	\$05	\$00	FFFFF5400	Ethernet
MVME376 #5	\$06	\$00	FFFFF5600	Ethernet
MVME376 #6	\$07	\$00	FFFFFA400	Ethernet
MVME374 #1	\$10	\$00	FFF000000	Ethernet
MVME374 #2	\$11	\$00	FFF100000	Ethernet
MVME374 #3	\$12	\$00	FFF200000	Ethernet
MVME374 #4	\$13	\$00	FFF300000	Ethernet
MVME374 #5	\$14	\$00	FFF400000	Ethernet
MVME374 #6	\$15	\$00	FFF500000	Ethernet

C


## Solving Startup Problems

In the event of difficulty with your CPU board, try the simple troubleshooting steps on the following pages before calling for help or sending the board back for repair. Some of the procedures will return the board to the factory debugger environment. (The board was tested under those conditions before it left the factory.) The self-tests may not run in all user-customized environments.

**Table D-1. Troubleshooting MVME162LX Boards**

Condition	Possible Problem	Try This:
I. Nothing works, no display on the terminal.	A. If the FUSES LED is not lit, the board may not be getting correct power.	<ol style="list-style-type: none"><li>1. Make sure the system is plugged in.</li><li>2. Check that the board is securely installed in its backplane or chassis.</li><li>3. Check that all necessary cables are connected to the board, per this manual.</li><li>4. Check for compliance with System Considerations, per this manual.</li><li>5. Review the Installation and Startup procedures, per this manual. They include a step-by-step powerup routine. Try it.</li></ol>
	B. If the LEDs are lit, the board may be in the wrong slot.	<ol style="list-style-type: none"><li>1. For VMEmodules, the CPU board should be in the first (leftmost) slot.</li><li>2. Also check that the "system controller" function on the board is enabled, per this manual.</li></ol>
	C. The "system console" terminal may be configured incorrectly.	Configure the system console terminal per this manual.

**Table D-1. Troubleshooting MVME162LX Boards (Continued)**

Condition	Possible Problem	Try This:
II. There is a display on the terminal, but input from the keyboard and/or mouse has no effect.	A. The keyboard or mouse may be connected incorrectly.	Recheck the keyboard and/or mouse connections and power.
	B. Board jumpers may be configured incorrectly.	Check the board jumpers per this manual.
	C. You may have invoked flow control by pressing a HOLD or PAUSE key, or by typing: <b>&lt;CTRL&gt;-S</b>	Press the HOLD or PAUSE key again. If this does not free up the keyboard, type in: <b>&lt;CTRL&gt;-Q</b>
III. Debug prompt 162-Bug> does not appear at power-up, and the board does not autoboot.	A. Debugger EPROM/Flash may be missing	<ol style="list-style-type: none"> <li>1. Disconnect <i>all</i> power from your system.</li> <li>2. Check that the proper debugger EPROM or debugger Flash memory is installed per this manual.</li> <li>3. Reconnect power.</li> <li>4. Restart the system by "double-button reset": press the RESET and ABORT switches at the same time; release RESET first, wait seven seconds, then release ABORT.</li> <li>5. If the debug prompt appears, go to step IV or step V, as indicated. If the debug prompt does not appear, go to step VI.</li> </ol>
	B. The board may need to be reset.	
IV. Debug prompt 162-Bug> appears at powerup, but the board does not autoboot.	A. The initial debugger environment parameters may be set incorrectly.	<ol style="list-style-type: none"> <li>1. Start the onboard calendar clock and timer. Type:  <b>set mmdyyhhmm &lt;CR&gt;</b>                      where the characters indicate the month, day, year, hour, and minute. The date and time will be displayed.                 </li> </ol> <div style="text-align: center;">   <b>Caution</b> </div> <p>Performing the next step (env;d) will change some parameters that may affect your system's operation.</p> <p style="text-align: right;">(continues&gt;)</p>
	B. There may be some fault in the board hardware.	



**Table D-1. Troubleshooting MVME162LX Boards (Continued)**

Condition	Possible Problem	Try This:
IV. <i>Continued</i>		<p>2. At the command line prompt, type in:  <b>env;d &lt;CR&gt;</b>  This sets up the default parameters for the debugger environment.</p> <p>3. When prompted to Update Non-Volatile RAM, type in:  <b>y &lt;CR&gt;</b></p> <p>4. When prompted to Reset Local System, type in:  <b>y &lt;CR&gt;</b></p> <p>5. After clock speed is displayed, immediately (within five seconds) press the Return key:  <b>&lt;CR&gt;</b>  or  <b>BREAK</b>  to exit to the System Menu. Then enter a 3 for “Go to System Debugger” and Return:  <b>3 &lt;CR&gt;</b>  Now the prompt should be:  162-Diag&gt;</p> <p>6. You may need to use the <b>cnfg</b> command (see your board Debugger Manual) to change clock speed and/or Ethernet Address, and then later return to:  <b>env &lt;CR&gt;</b>  and step 3.</p> <p>7. Run the selftests by typing in:  <b>st &lt;CR&gt;</b>  The tests take as much as 10 minutes, depending on RAM size. They are complete when the prompt returns. (The onboard selftest is a valuable tool in isolating defects.)</p> <p>8. The system may indicate that it has passed all the selftests. Or, it may indicate a test that failed. If neither happens, enter:  <b>de &lt;CR&gt;</b>  Any errors should now be displayed. If there are any errors, go to step VI. If there are no errors, go to step V.</p>

**Table D-1. Troubleshooting MVME162LX Boards (Continued)**

Condition	Possible Problem	Try This:
V. The debugger is in system mode and the board autoboots, or the board has passed selftests.	A. No apparent problems — troubleshooting is done.	No further troubleshooting steps are required.
VI. The board has failed one or more of the tests listed above, and cannot be corrected using the steps given.	A. There may be some fault in the board hardware or the on-board debugging and diagnostic firmware.	<ol style="list-style-type: none"> <li>1. Document the problem and return the board for service.</li> <li>2. Phone 1-800-222-5640.</li> </ol>
TROUBLESHOOTING PROCEDURE COMPLETE.		

D

## Numerics

- 162Bug 4-1
  - installation 3-3
- 162Bug (MVME162Bug) 2-3
- 162Bug command set 4-20
- 162Bug default controller and device parameters 3-19
- 162Bug firmware 3-1
- 162Bug implementation 3-3
- 162Bug stack space 3-14
- 162Bug static variable space 3-14
- 162Bug vector table and workspace 4-13
- 172Bug
  - implementation of 3-3
- 27C040 EPROM 3-3
- 82596CA 1-23

## A

- Abort function 3-11
- ABORT switch 1-14
- address (command syntax) 4-3
- address formats 4-6, 4-7
- address range 1-28
- address ranges, EPROM 2-10
- address/data configurations 2-18
- addresses as command parameters 4-5
- addressing disk/tape controllers B-1
- addressing mode, extended 2-18
- arguments, command line 4-3
- arithmetic operators 4-3
- ASCII string (command syntax) 4-3
- ASICs
  - MC2chip 2-10, 2-12

- VMEchip2 1-21

- ASICs used on board 1-2
- assembler/disassembler, creating a program with 4-10
- assertion, definition of 1-13
- autoboot function 3-7
- autojumping function 2-17

## B

- backplane jumpers 2-17
- Backus-Naur syntax, debugger commands and 4-3
- base address, DRAM 2-18
- base and top addresses 4-7
- base identifier, numeric values and 4-4
- battery 1-19
- battery-backed-up RAM (BBRAM) and clock 1-21, A-3
- BBRAM (battery-backed-up RAM) 1-21
- BG (bus grant) signal 2-17
- BH (bootstrap and halt) command 3-17
- binary numbers 1-12
- block diagram 1-14
- blocks versus sectors 3-15
- BO (bootstrap operating system) command 3-17
- board configuration 2-1
- board layout 2-2
- boot functions
  - autoboot 3-7
  - network boot 3-10
  - ROMboot 3-9
- BOOTP protocol module 3-21

- Break function 3-12
- BREAK key 3-12
- bus grant (BG) signal 2-17
- byte, definition of 1-13
- C**
- C programming language 3-3
- cable(s) 2-17
- checksum, testing NVRAM contents with A-3
- CLUN (controller LUN) B-2, C-1
- command identifier, debugger 4-3
- command lines, debugger 4-1
- command syntax, debugger 4-3
- commands
  - Configure Board Information Block (CNFG) A-1
  - Set Environment (ENV) A-3
- configuration, hardware 3-4
- configuring IndustryPacks A-14
- configuring the board 2-1
- configuring VMEbus interface A-10
- connections, serial cable 2-20
- connectors on J17 (serial) 4-9
- connectors, MVME162LX 1-27
- console port 4-9
- control bit, definition of 1-13
- control module, network boot 3-21
- controller and device parameters, 162Bug 3-19
- controller LUN (CLUN) B-2, C-1
- cooling requirements 1-10
- count (command syntax) 4-3
- creating a program 4-10
- D**
- data bus structure 1-16
- data terminal equipment (DTE) 1-22
- date and time, setting 3-7
- debug monitor 2-3
- debug port 4-9
- debugger
  - address parameter formats 4-6
  - debugger command set 4-20
  - debugger commands
    - Configure Board Information Block (CNFG) A-1
    - Set Environment (ENV) A-3
  - debugger overview 3-1
  - debugger prompt 4-1
  - debugger prompts 3-2
  - decimal numbers 1-12
  - default configuration, disk/tape controller B-2
  - description of 162Bug 3-1
  - device LUN (DLUN) B-2, C-1
  - device probe function, 162Bug 3-16
  - diagnostic facilities 3-25
  - direct access devices B-2, B-3
  - directories
    - switching 3-25
  - disk I/O error codes 3-19
  - disk I/O support 3-15
  - disk I/O via 162Bug commands 3-16
  - disk I/O via 162Bug system calls 3-17
  - Disk I/O via 172Bug Commands 3-16
  - disk/tape controller data B-1
  - DLUN (device LUN) B-2, C-1
  - documentation
    - non-Motorola 1-5
    - other applicable Motorola publications 1-4
  - double precision real (floating point format) 4-19
  - double-button reset 3-11, D-2
  - downloading S-record object files 4-10
  - DRAM (dynamic RAM)
    - options 1-17
  - DRAM base address 2-18
  - DTE (data terminal equipment) 1-22
- E**
- ECC DRAM 2-13
- EIA-232-D ports 3-5, 4-13

---

- elevated-temperature operation 1-10
- entering and debugging programs 4-9
- entering debugger command lines 4-1
- ENV command parameters A-4
- EPROM (see 27C040 EPROM) 3-3
- EPROM address ranges 2-10
- EPROM and Flash memory 1-21
- EPROM sockets 2-9
- EPROM/Flash mapping 2-11
- EPROM/Flash selection 2-12
- error codes, disk I/O 3-19
- error codes, network I/O 3-22
- Ethernet C-1
  - station address 1-23
- Ethernet driver 3-20
- Ethernet interface 1-23
- exception vectors, 162Bug 4-13
- exponent field (floating point support) 4-18
- expression (command syntax) 4-3
- expressions as parameters 4-3
- extended addressing mode 2-18

## F

- false, definition of 1-13
- FCC compliance 1-12
- features 1-6
- firmware 2-3
- firmware console 3-5
- firmware implementation 3-3
- firmware overview 3-1
- Flash memory 2-9, 3-3, 3-7
  - initializing 3-7
- flexible diskettes, accessing B-2
- floating point instructions 4-18
- floating point unit (FPU) 4-18, 4-20
- floppy disk command parameters B-4
- format, S-record 4-10
- FPU (floating point unit) 4-18, 4-20
- front panel switches and indicators 1-14
- functional description 1-14

## G

- GCSR (global control/status register)
  - GPCSR0 bit A-8
- GCSR (global control/status registers) 2-19
- global bus timeout 2-18
- global control/status registers (GCSR) 2-19

## H

- handshaking, forms of 3-6
- hardware configuration 3-4
- hardware features, description of 1-1
- hardware functions, 162Bug 4-13
- hardware interrupts 1-26
- hexadecimal characters 1-12
- high-temperature operation 1-10
- host port 4-9
- host systems, downloading object files from 4-10

## I

- I/O support, network 3-19
- IACK (interrupt acknowledge) signal 2-17
- indicators 1-14
- IndustryPack (IP) modules 1-23
- IndustryPacks
  - defining general control requirements A-15
  - defining interrupt control requirements A-16
  - defining memory size requirements A-15
- IndustryPacks, configuring A-14
- input/output control, terminal 4-1
- installation
  - considerations 2-18
  - IP (IndustryPack) 2-15
  - MVME162LX 2-16, 2-18
- installation and startup 3-3
- instructions, floating point 4-18

- 
- Intel 82596 LAN coprocessor Ethernet driver 3-20
  - interface
    - Ethernet 1-23
    - IndustryPack (IP) 1-23
    - SCSI 1-24
    - serial 1-22
    - serial communications 2-19
    - VMEbus 1-21
  - interprocessor communication 3-22
  - interrupt acknowledge (IACK) signal 2-17
  - Interrupt Stack Pointer (ISP) 3-14
  - interruptions, hardware 1-26
  - IOC (I/O control) command 3-17
  - IOI (input/output inquiry) command 3-16
  - IOP (physical I/O to disk) command 3-16
  - IOT (I/O teach) command 3-17
  - IOT command parameters for supported floppy types B-4
  - IP (IndustryPack) installation 2-15
  - IP32 CSR bit 2-5
  - ISP (Interrupt Stack Pointer) 3-14
- J**
- jumper headers 3-3
    - J21 (general-purpose readable jumpers) 1-17
  - jumper headers, setting 2-3
  - jumper settings 2-2
  - jumpers
    - backplane 2-17
    - J1 (system controller selection) 2-3
    - J11 (IP bus clock) 2-5, 3-5
    - J12 (SCSI terminator configuration) 2-6
    - J14 (SRAM backup power source) 2-6
    - J16 (Flash write protection) 2-7
    - J18 (IP bus strobe selection) 2-8
    - J18 (IP bus strobe) 3-5
    - J19 (IP DMA snoop control) 2-8, 3-5
    - J20 (EPROM/Flash configuration) 2-9
    - J21 (general-purpose readable jumpers) 2-12
    - user-definable 2-12
- L**
- LAN driver 3-20
  - LAN interface 1-23
  - LEDs 1-14
  - local bus
    - access from VMEbus 1-34
  - local bus arbiter 1-27
  - local bus timeout function 1-26
  - local processor resources 1-25
  - location monitors, GCSR and 2-19
  - longword, definition of 1-13
- M**
- mantissa field (floating point support) 4-18
  - manufacturing test process 3-25
  - mapping, EPROM/Flash 2-11
  - MC2chip 2-10, 2-12
  - MC68040 cache 1-16
  - MC68040 MPU 1-16
  - MC68040 TRAP instructions 4-11
  - memory
    - EPROM and Flash 1-21
  - memory boards 2-13
  - memory map
    - local bus 1-28
    - local I/O devices 1-31
    - VMEbus 1-34
    - VMEbus short I/O 1-34
  - memory mezzanine options 2-13
  - memory mezzanines
    - stacking options 2-14
  - memory options 1-17
  - memory requirements, 162Bug 3-13
  - metasymbols, command syntax and 4-3
  - mezzanine boards 2-13

---

microprocessor, description of 1-16  
MPCR (Multiprocessor Control Register)  
    method 3-22  
MPU clock speed calculation 3-13  
Multiprocessor Control Register (MPCR)  
    3-22  
Multiprocessor Control Register (MPCR)  
    method 3-22  
multiprocessor support 3-22  
MVME162Bug 1-17, 3-1  
MVME162Bug (162Bug) 2-3  
MVME162LX block diagram 1-15  
MVME162LX features 1-6  
MVME162LX installation 2-16  
MVME162LX specifications 1-9  
MVME172 C-1  
MVME328 SCSI controller B-1, B-2, B-3  
MVME374 C-1  
MVME376 C-1

## N

negation, definition of 1-13  
network boot control module 3-21  
network boot function 3-10  
network controller modules supported  
    C-1  
network I/O error codes 3-22  
network I/O support 3-19  
non-volatile RAM (NVRAM) A-3  
normal address range 1-28  
no-VMEbus-interface option 1-17, 3-7  
numeric values and base identifiers 4-4  
NVRAM (non-volatile RAM) A-3

## O

object code 4-10  
offset registers 4-7  
operating environment, debugger 4-11  
operating temperature 1-10  
operating the board 3-3  
operational parameters, 162Bug A-3  
option field, command line 4-3

overview 1-1

## P

parameters, 162Bug 3-19  
parity DRAM 2-13  
port 0 or 00 4-9  
port 1 or 01 4-9  
port 2 or 02 4-9  
port 3 or 03 4-9  
port number(s) 4-3  
port numbers 4-9  
program execution, remote 3-22  
programs, entering and debugging 4-9  
prompt, debugger 4-1  
protocol modules  
    BOOTP 3-21  
    RARP/ARP 3-21  
    UDP/IP 3-20  
protocol modules, TFTP 3-21  
pseudo-registers 4-7  
publications  
    Non-Motorola 1-5

## R

range (command syntax) 4-3  
RARP/ARP protocol modules 3-21  
reading a program from disk 4-10  
registers, offset 4-7  
related documentation 1-3  
relative address+offset 4-7  
remote program execution 3-22  
Reset function 3-11  
RESET switch 1-14  
resetting the system 3-10  
RF emissions 1-12, 2-16  
ROMboot function 3-9

## S

scientific notation (floating point format)  
    4-20  
SCSI controllers B-1, B-2, B-3  
SCSI interface 1-24

SCSI termination 1-24  
 SCSI terminator configuration 1-24, 2-6  
 SD command 3-25  
 serial cable connections 2-20  
 serial communications 2-19  
 serial communications Controllers  
     (Z85230s) 3-6  
 serial ports 3-5, 4-13  
     default baud rate 3-5  
 serial ports 1-4 4-9  
 shielded cables 2-17  
 sign field (floating point support) 4-18  
 single precision real 4-19  
 single precision real (floating point format) 4-19  
 slave address decoders, VMEbus interface A-10  
 software-programmable hardware interrupts 1-26  
 source lines, entering 4-10  
 specifications 1-9  
 SRAM (Static RAM)  
     options 1-18  
 SRAM battery 1-19  
 S-record files, downloading 4-10  
 S-record format 4-10  
 stacking mezzanine boards 2-13  
 startup, MVME162LX 3-3  
 status bit, definition of 1-13  
 string literals, numeric values and 4-4  
 switches 1-14  
 switching directories 3-25  
 syntactic variables, command lines and 4-3  
 SYSFAIL\* signal  
     assertion/negation 3-12  
 system calls, 162Bug 3-17  
 system console 3-5  
 system controller function 3-5  
 System Fail (SYSFAIL\*) signal 3-9  
 system utilities, calling from user programs 4-11

**T**

terminal input/output control 4-1  
 termination, SCSI 1-24  
 TFTP protocol module 3-21  
 tick timers 1-25  
 timeout function  
     local bus 1-26  
 timeout, global bus 2-18  
 timers, programmable 1-25  
 transfer type (TT) signals 1-28  
 TRAP #15 utilities 4-11  
 TRAP instructions 4-11  
 troubleshooting procedures D-1  
 true, definition of 1-13

**U**

UDP/IP protocol modules 3-20  
 unpacking the equipment 2-1  
 user-definable jumpers 2-12  
 using the 162Bug debugger 4-1  
 utilities, TRAP #15 4-11

**V**

vector table, 162Bug 4-12  
 vector tables, creating 4-16  
 VMEbus  
     specification 1-5  
 VMEbus access to local bus 1-34  
 VMEbus interface 1-21  
     slave address decoders A-10  
 VMEbus interface, configuring A-10  
 VMEbus, "no" option 3-7  
 VMEchip2 1-21  
     GCSR (Global Control and Status Registers)ASICs  
     VMEchip2 3-24

**W**

watchdog timer 1-25



---

**Z**

Z85230 serial communications controllers (SCCs) 3-6

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>