Package Contents

17" Dual-Rail LCD Rack Console

Side-Rail Kit

VGA, PS/2 Cable Kit

IEC Power Cable

Quick Installation Guide

Keys

Introduction

This booklet will guide you through the basic steps needed to install the 17" LCD Rack Console with Dual-Rail Technology.

Specifications

Material	Heavy-duty steel
Power	Auto-switching 100 to 240VAC 50 to 60Hz 48 watts
Net Weight	32.6 lbs. (14.8kg.)
Unit Dimensions	19 (W) x 26.3 (D) x 1.70 (H) in. (483.2 x 668.51 x 43.18mm)
Minimum Rack-Mount Depth	26 in. (660.4mm)
Maximum Rack-Mount Depth	36 in. (914.4mm)
Display Type	17" TFT/LCD active-matrix color
Resolution	Up to 1280x1024
Contrast Ratio	450:1
Brightness	250 cd/m2 typical
Pixel Pitch	0.264mm x 0.264mm

Panel Color	16.7 million display colors
Response Time	Rising 2ms, Decay 14ms
Keyboard Type	Laptop style
Keyboard Connection	PS/2
Mouse Type	Touchpad style
Mouse Connection	PS/2
Operating Life of Individual Keys	8 million cycles
Warranty	2 years

Key-Locking Mechanism

LCD Front-Panel Controls

105-Key Keyboard

Touch Pad

TFT/LCD Active-Matrix Color Panel

On/Off

Auto

**Up**

Down

Menu

Installation

Step 1   Place the console inside the rack.

Step 2   Mount the front brackets to the rack.


Step 3   Slide the side rails onto the mounting studs.

**Step 4**   Mount the side rails to the rear of the rack.

Step 5   Connect the IEC power cable to an active power
outlet and power up the Console.

Connecting the KVM Switch or Server

Step 1   Make sure your KVM switch or server is powered OFF.

Step 2   Using the included PS/2 KVM Cable Kit, connect one set of VGA and PS/2 connectors to the back of the Console. (Refer to diagrams below.)

Step 3   Connect the other end of the Cable Kit to the console monitor, keyboard, and mouse ports on your KVM switch or server. (Refer to diagrams below.)

Step 4   Power ON the Console.

Step 5   Power ON the KVM switch or server connected to the Console.

You are now ready to use your LCD Rack Console.

Console

KVM Switch

Console

Server

The Console offers two power on/off methods:

• a power button on the LCD front-panel console, and
• an LCD power-save (with drawer closure).

Troubleshooting

My Console doesn't appear to be on.

Make sure that the power switch located at the front of the keyboard drawer is "on" and that the power cable is connected properly.

What is the maximum video resolution that the LCD panel supports?

The LCD panel supports a resolution of up to 1280x1024.

Do I have to install any software to use the Console?

No, the Console does not require any drivers or software to be installed in your computers. Simply connect the Console directly to a computer or to a KVM switch, and it is ready for use.

Start Here→

Quick Installation Guide

BELKIN.

Titan 17" Dual-Rail LCD Rack Console

BELKIN.

www.belkin.com

PM01576

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com